# M4 Macros for Electric Circuit Diagrams in $\ensuremath{\measuredangle\mbox{T}_{\ensuremath{E}\mbox{X}}}\xspace$ Documents

Dwight Aplevich

## Version 6.7

## Contents

1	Introduction	<b>2</b>			
2	Using the macros         2.1       Quick start         2.1.1       Processing with dpic and PSTricks or Tikz PGF         2.1.2       Processing with gpic         2.1.3       Simplifications	<b>2</b> 2 3 3 4			
3	Pic essentials         3.1 Manuals         3.2 The linear objects: line, arrow, spline, arc         3.3 The planar objects: box, circle, ellipse, and text         3.4 Compound objects         3.5 Other language facilities	<b>5</b> 5 6 7 7			
4	Two-terminal circuit elements         4.1       Circuit and element basics         4.2       The two-terminal elements         4.3       Branch-current arrows         4.4       Labels	8 9 12 13			
5	Other circuit elements	13			
6	Directions, rotations, and macro-level looping	19			
7	Logic gates	20			
8	Element and diagram scaling	<b>23</b> 24 24			
9	Writing macros	<b>25</b>			
10	) Interaction with IATEX	26			
11	PSTricks and other tricks	28			
12	Web documents, pdf, and alternative output formats	29			
13 Developer's notes 30					
14 Bugs 30					
15	List of macros	33			

## 1 Introduction

Before every conference, I find Ph.D.s in on weekends running back and forth from their offices to the printer. It appears that people who are unable to execute pretty pictures with pen and paper find it gratifying to try with a computer [9].

This document describes a set of macros, written in the m4 macro language [7], for producing electric circuits and other diagrams in ETEX documents. The macros evaluate to drawing commands in pic, a line-drawing language [8] that is readily available and simple to learn. The result is a system with the advantages and disadvantages of TEX itself, since it is macro-based and non-wysiwyg, and since it uses ordinary character input. The book from which the above quotation is taken correctly points out that the payoff can be in quality of diagrams at the price of the time spent in learning how to draw them.

A collection of basic components and conventions for their internal structure are described. It is often convenient to customize elements or to package combinations of them for particular drawings, so macros such as these are only a starting point.

## 2 Using the macros

This section describes the basic process of adding circuit diagrams to LATEX documents to produce postscript or pdf files. On some operating systems, project management software with graphical interfaces can be used to automate the process but, for simple documents, the steps can be performed by hand as described in Section 2.1.

The diagram source file is preprocessed as illustrated in Figure 1. The predefined macros, followed by the diagram source, are read by m4. The result is passed through a pic interpreter to produce .tex output that can be inserted into a .tex document using the \input command.



Figure 1: Inclusion of figures and macros in the LATEX document. Replacing LATEX with PDF latex to produce pdf directly is also possible.

Depending on the pic interpreter chosen, the choice of options, and the choice of  $IAT_EX$  or PDFlatex, the interpreter output may contain tpic specials,  $IAT_EX$  graphics, PSTricks [13] commands, Tikz PGF commands, or other formats. These variations are described in Section 12.

There are two principal choices of pic interpreter. One is dpic, described later in this document. An alternative [3] is gpic -t together with a printer driver that understands tpic specials, typically [11] dvips. In some installations, gpic is simply named pic, but make sure that GNU pic [3] is being invoked rather than the older Unix pic. Pic processors contain basic macro facilities, so some of the concepts applied here require only a pic processor. By judicious use of macros, features of both m4 and pic can be exploited.

#### 2.1 Quick start

The contents of file quick.m4 and resulting diagram are shown in Figure 2 to illustrate the language, to show several ways for placing circuit elements, and to provide sufficient information for producing basic labeled circuits.

To process the file, make sure that the libraries libcct.m4 and libgen.m4 are installed and readable. Verify that m4 is installed. Now there are at least two possibilities, described in the following subsections, with slightly simpler usage to be given in Section 2.1.3.

```
.PS
                               # Pic input begins with .PS
                               # Set defaults
cct_init
elen = 0.75
                               # Variables are allowed; default units are inches
Origin: Here
                               # Position names are capitalized
   source(up_ elen); llabel(-,v_s,+)
   resistor(right_ elen); rlabel(,R,)
   dot
   {
                               # Save current position and direction
      capacitor(down_ to (Here,Origin))
                                             #(Here,Origin) = (Here.x,Origin.y)
      rlabel(+,v,-); llabel(,C,)
      dot.
                                                                              R
                               # Restore position and direction
      }
   line right_ elen*2/3
   inductor(down_ Here.y-Origin.y); rlabel(,L,); b_current(i)
   line to Origin
.PE
                               # Pic input ends
```

Figure 2: The file quick.m4 and resulting diagram.

#### 2.1.1 Processing with dpic and PSTricks or Tikz PGF

If you are using dpic with PSTricks, type the following commands or put them into a script:

```
m4 <path>pstricks.m4 <path>libcct.m4 quick.m4 > quick.pic
dpic -p quick.pic > quick.tex
```

where <path> is the path to the libcct.m4 file. Put \usepackage{pstricks} in the main LATEX source file header and the following in the body:

```
\begin{figure}[hbt]
   \centering
   \input quick
   \caption{Customized caption for the figure.}
   \label{Symbolic_label}
\end{figure}
```

This distribution is compatible with the Tikz PGF drawing commands, which have nearly the power of the PSTricks package with the ability to produce pdf output by running the pdflatex command instead of latex on the input file. The commands are modified to read pgf.m4 and invoke the dpic -g option as follows:

```
m4 <path>pgf.m4 <path>libcct.m4 quick.m4 > quick.pic
dpic -g quick.pic > quick.tex
```

The LATEX header should contain \usepackage{tikz}, but the inclusion statements are the same as for PSTricks input.

In all cases the essential line is \input quick, which inserts the previously created file quick.tex. Then LATEX the document, convert to postscript typically using dvips, and print the result or view it using Ghostview. The alternative for Tikz PGF output of dpic -g is to invoke PDF latex.

#### 2.1.2 Processing with gpic

If your printer driver understands tpic specials and you are using gpic (on some systems the gpic command is pic), the commands are

m4 <path>libcct.m4 quick.m4 > quick.pic
gpic -t quick.pic > quick.tex

The figure inclusion statements are as shown:

```
\begin{figure}[hbt]
   \input quick
   \centerline{\box\graph}
   \caption{Customized caption for the figure.}
   \label{Symbolic_label}
   \end{figure}
```

#### 2.1.3 Simplifications

• If appropriate include() statements are placed at the top of the file quick.m4, then the m4 commands illustrated above can be shortened to

```
m4 quick.m4 > quick.pic
```

For example, the following two lines can be inserted before the line containing .PS:

```
include(<path>pstricks.m4)
include(<path>libcct.m4)
```

where **<path>** is the path to the folder containing the libraries. Only the second line is necessary if gpic is used or if the libraries were installed so that PSTricks is assumed by default.

• On some systems, setting the environment variable M4PATH to the library folder allows the above lines to be simplified to

```
include(pstricks.m4)
include(libcct.m4)
```

• In the absence of a need to examine the file quick.pic, the commands for producing the .tex file can be reduced to

```
m4 quick.m4 | dpic -p > quick.tex
```

- When many files are to be processed, then a facility such as Unix "make," which is also available in several PC versions, can be employed to automate the commands given above. On systems without such a facility, a scripting language can be used.

```
\newcommand{\diaA}{%
.PS
drawing commands
.PE
\box\graph }% \box\graph not required for dpic
\newcommand{\diaB}{%
.PS
drawing commands
.PE
\box\graph }% \box\graph not required for dpic
Process the file using m4 and dpic or gpic to produce a .tex file, insert this into the LATEX
source using \input, and invoke the macros at the appropriate places.
```

• It may be desirable to invoke m4 and dpic automatically from the document file, as shown:

```
\documentclass{article}
\usepackage{tikz}
\newcommand\mtopgf[1]{\immediate\write18{m4 <path>/pgf.m4 #1.m4 | dpic -g > #1.tex}}%
\begin{document}
```

```
\mtopgf{PicA}
\input{PicA.tex} \par
\mtopgf{PicB}
\input{PicB.tex}
\end{document}
```

The path to pgf.m4 must be defined in this file, sources PicA.m4 and PicB.m4 must contain any required include statements, and the document file should be processed using the command pdflatex -shell-escape <filename>. This method processes each picture source every time LATEX is run, so for large documents containing many graphics, the \mtopgf line could be commented out after debugging the corresponding graphic.

## 3 Pic essentials

Pic source is a sequence of lines in a file. The first line of a diagram begins with .PS with optional following arguments, and the last line is normally .PE. Lines outside of these pass through the pic processor unchanged.

The visible objects can be divided conveniently into two classes, the *linear* objects line, arrow, spline, arc, and the *planar* objects box, circle, ellipse.

The object move is linear but draws nothing. A composite object, or block, is planar and consists of a pair of square brackets enclosing other objects, as described in Section 3.4. Objects can be placed using absolute coordinates or relative to other objects.

Pic allows the definition of real-valued variables, which are alphameric names beginning with lower-case letters, and computations using them. Objects or locations on the diagram can be given symbolic names beginning with an upper-case first letter.

#### 3.1 Manuals

At the time of writing, the classic pic manual [8] can be obtained from URL:

http://www.cs.bell-labs.com/10thEdMan/pic.pdf

A more complete manual [10] is included in the GNU groff package. A compressed postscript version is available, at least temporarily, with these circuit files.

In both of the above manuals, explicit use of **\*roff** string and font constructs should be replaced by their  $ET_EX$  equivalents as necessary. Further explanation is available, for example, from the gpic "man" page, part of the GNU groff package.

Examples of use of the circuit macros in an electronics course are available on the web [2].

For a discussion of "little languages" for document production, and of pic in particular, see Chapter 9 of [1]. Chapter 1 of [5] also contains a brief discussion of this and other languages.

#### 3.2 The linear objects: line, arrow, spline, arc

A line can be drawn as follows:

line from position to position

where *position* is defined below or

line direction distance

where *direction* is one of up, down, left, right. When used with the m4 macros described here, it is preferable to add an underscore: up\_, down\_, left\_, right\_. The *distance* is a number or expression and the units are inches, but the assignment

scale = 25.4

has the effect of changing the units to millimetres, as described in Section 8.

Lines can also be drawn to any distance in any direction. The example,

line up\_ 3/sqrt(2) right\_ 3/sqrt(2)

draws a line 3 units long from the current location, at a  $45^\circ$  angle above horizontal. The construction

line from A to B chop x

truncates the line at each end by  $\mathbf{x}$  or, if  $\mathbf{x}$  is omitted, by the current circle radius, which is convenent when A and B are symbolic names for circular graph nodes, for example. Otherwise

line from A to B chop x chop y

truncates the line ends by x and y, which may be negative.

The above methods of specifying the direction and length of a line are referred to as a *linespec*. Lines can be concatenated. For example, to draw a triangle:

line up\_ sqrt(3) right\_ 1 then down\_ sqrt(3) right\_ 1 then left\_ 2

A position can be defined by a coordinate pair, e.g. 3,2.5, more generally using parentheses by (expression, expression), or by the construction (position, position), the latter taking the xcoordinate from the first position and the y-coordinate from the second. A position can be given a symbolic name beginning with an upper-case letter, e.g. Top: (0.5,4.5). Such a definition does not affect the calculated figure boundaries. The current position Here is always defined and is equal to (0,0) at the beginning of a diagram or block. The coordinates of a position are accessible, e.g. Top.x and Top.y can be used in expressions. The center, start, and end of linear objects are valid positions, as shown in the following example, which also illustrates how to refer to a previously drawn element if it has not been given a name:

line from last line.start to 2nd last arrow.end then to 3rd line.center

Objects can be named (using a name commencing with an upper-case letter), for example:

Bus23: line up right

after which, positions associated with the object can be referenced using the name; for example: arc cw from Bus23.start to Bus23.end with .center at Bus23.center

An arc is drawn by specifying its rotation, starting point, end point, and center, but sensible defaults are assumed if any of these are omitted. Note that

arc cw from Bus23.start to Bus23.end

does not define the arc uniquely; there are two arcs that satisfy this specification. This distribution includes the m4 macros

arcr( position, radius, start radians, end radians)

arcd( position, radius, start degrees, end degrees)

arca( chord linespec, ccw|cw, radius, modifiers)

to draw uniquely defined arcs. For example,

arcd((1,1),2,0,-90) -> dashed cw

draws a clockwise arc with centre at (1, 1), radius 2, from (3, 1) to (1, -1), and arca(from (1, 1) to (2, 2), 1, ->)

draws an acute-angled arc with arrowhead on the chord defined by the first argument.

The linear objects can be given arrowheads at the start, end, or both ends, for example: line dashed <- right 0.5

arc <-> height 0.06 width 0.03 ccw from Here to Here+(0.5,0)  $\setminus$ 

with .center at Here+(0.25,0)

spline -> right 0.5 then down 0.2 left 0.3 then right 0.4

The arrowheads on the arc above have had their shape adjusted using the height and width parameters.

Finally, lines can be specified as dotted, dashed, or invisible, as in the above example.

#### 3.3 The planar objects: box, circle, ellipse, and text

The planar objects are drawn by specifying the width, height, and center position, thus:

A: box ht 0.6 wid 0.8 at (1,1)

after which, in this example, the position A.center is defined, and can be referenced simply as A. In addition, the compass corners A.n, A.s, A.e, A.w, A.ne, A.se, A.sw, A.nw are automatically defined, as are the dimensions A.height and A.width. For example, two touching circles can be drawn as shown:

circle radius 0.2 circle diameter (last circle.width \* 1.2) with .sw at last circle.ne The planar objects can be filled with gray or colour; thus box dashed fill produces a dashed box filled with a medium gray by default. The gray density can be controlled using the fill\_(number) macro, where  $0 \le number \le 1$ , with 0 corresponding to black and 1 to white.

Basic colours for lines and fills are provided by gpic and dpic, but more elaborate line and fill styles can be incorporated, depending on the printing device, by inserting **\special** commands or other lines beginning with a backslash in the drawing code. In fact, arbitrary lines can be inserted into the output using

command "string"

where *string* is the line to be inserted.

Arbitrary text strings, typically meant to be typeset by IATEX, are delimited by double-quote characters and occur in two ways. The first way is illustrated by

"\large Resonances of  $C_{20}H_{42}$ " wid x ht y at position

which writes the typeset result, like a box, at *position* and tells pic its size. The default size assumed by pic is given by parameters **textwid** and **textht** if it is not specified as above. The exact typeset size of formatted text can be obtained as described in Section 10. The second occurrence associates one or more strings with an object, e.g., the following writes two words, one above the other, at the centre of an ellipse:

ellipse "\bf Stop" "\bf here"

The C-like pic function sprintf("format string", numerical arguments) is equivalent to a string.

#### 3.4 Compound objects

A compound object is a group of statements enclosed in square brackets. Such an object is placed by default as if it were a box, but it can also be placed by specifying the final position of an internal location. Consider the example code fragment shown:

Ands: [ right\_

```
And1: AND_gate
And2: AND_gate at And1 - (0,And1.ht*3/2)
line from And1.Out right_ And1.wid/3 then down_ (And1.y-And2.y)/2 then \
    left_ And1.wid*5/3 then to And2.In1-(And1.wid/3,0) then to And2.In1
...
l with And2 In1 et (K = ICE Dip0 m)
```

```
] with .And2.In1 at (K.x,IC5.Pin9.y)
```

The two gate macros evaluate to compound objects containing Out, In1, and other locations. The final positions of all objects between the square brackets are specified in the last line by specifying the position of In1 of gate And2.

#### 3.5 Other language facilities

All objects have default sizes, directions, and other characteristics, so part of the specification of an object can sometimes be profitably omitted.

Another possibility for defining positions is

expression of the way between position and position which is abbreviated as

expression < position, position >

but care has to be used in processing the latter construction with m4, since the comma may have to be put within quotes, ',' to distinguish it from the m4 argument separator.

Positions can be calculated using expressions containing variables. The scope of a position is the current block. Thus, for example,

theta = atan2(B.y-A.y,B.x-A.x)

line to Here+(3\*cos(theta),3\*sin(theta)).

Expressions are the usual algebraic combinations of primary quantities: constants, environmental parameters such as scale, variables, horizontal or vertical coordinates of terms such as position.x or position.y, dimensions of pic objects, e.g. last circle.rad. The elementary algebraic operators are +, -, \*, /, %, =, +=, -=, \*=, /=, and %=, similar to the C language. The logical operators ==, !=, <=, >=, >, and < apply to expressions, and strings can be tested for equality or inequality. A modest selection of numerical functions is also provided: the singleargument functions sin, cos, log, exp, sqrt, int, where log and exp are base-10, the twoargument functions atan2, max, min, and the random-number generator rand(). Other functions are also provided using macros.

A pic manual should be consulted for details, more examples, and other facilities, such as the branching facility

if expression then { anything } else { anything },
the looping facility

for variable = expression to expression by expression do { anything },
operating-system commands, pic macros, and external file inclusion.

## 4 Two-terminal circuit elements

There is a fundamental difference between two-terminal elements, which are drawn as directed linear objects, and other elements, which are compound objects as described in Section 3.4. The two-terminal element macros follow a set of conventions described in this section, and other elements will be described in Section 5.

#### 4.1 Circuit and element basics

First, the arguments of all drawing macros have default values, so that only arguments that differ from these values need be specified. The arguments are given in Section 15.

Consider the resistor shown in Figure 3, which also serves as an example of pic commands. The first part of the source file for this figure is as follows:

.PS

```
cct_init
linewid = 2.0
linethick_(2.0)
```

R1: resistor



Figure 3: Resistor named R1, showing the size parameters, enclosing block, and predefined positions.

The lines of Figure 3 and the remaining source lines of the file are explained below:

- The first line invokes an almost-empty macro cct\_init that initializes local variables needed by some circuit-element macros. This macro can be customized to set line thicknesses, maximum page sizes, scale parameters, or other global quantities as desired.
- The body dimensions of two-terminal elements are multiples of the macro dimen\_, which evaluates by default to linewid, the pic environmental parameter with default value 0.5 in. The default length of an element is elen\_, which is dimen\_\*3/2. Setting linewid to 2.0 as in the example means that the default element length becomes 3.0 in. For resistors, the length of the body is dimen\_/2, and the width is dimen\_/6. All of these values can be customized. Element scaling is discussed further in Section 8.

- The macro linethick\_ sets the thickness of subsequent lines (to 2.0 pt in the example). In the m4 language, macro arguments are written within parentheses following the macro name, with no space between the name and the opening parenthesis. Lines can be broken before a macro argument because m4 ignores white space immediately preceding arguments.
- The two-terminal element macros expand to sequences of drawing commands that begin with 'line invis *linespec*', where *linespec* is the first argument of the macro if it is non-blank, otherwise by default the line is drawn a distance elen\_ in the current direction, which is to the right by default. The invisible line is first drawn, then the element is drawn on top of it. The element—rather the initially drawn invisible line—can be given a name, R1 in the example, so that positions R1.start, R1.centre, and R1.end are defined as shown.
- The element body is enclosed by a block, which later can be used to place labels around the element. The block corresponds to an invisible rectangle with horizontal top and bottom lines, regardless of the direction in which the element is drawn. In the diagram a dotted box has been drawn to show the block boundaries.
- The last sub-element, identical to the first in two-terminal elements, is an invisible line that can be referenced later to place labels or other elements. This might be over-kill. If you create your own macros you might choose simplicity over generality, and only include visible lines.

To produce Figure 3, the following embellishments were included after the previously shown source:

```
thinlines_
box dotted wid last [].wid ht last [].ht at last []
move to 0.85<last [].sw,last [].se>
spline <- down arrowht*2 right arrowht/2 then right 0.15; "\tt last []" ljust
arrow <- down 0.3 from R1.start chop 0.05; "\tt R1.start" below
arrow <- down 0.3 from R1.end chop 0.05; "\tt R1.end" below
arrow <- down last [].c.y-last arrow.end.y from R1.c; "\tt R1.centre" below
dimension_(from R1.start to R1.end,0.45,\tt elen\_,0.4)
dimension_(right_ dimen_ from R1.c-(dimen_/2,0),0.3,\tt dimen\_,0.5)
.PE
```

- The line thickness is set to the default thin value of 0.4 pt, and the box displaying the element body block is drawn. Notice how the width and height can be specified, and the box centre positioned at the centre of the block.
- The next paragraph draws two objects, a spline with an arrowhead, and a string left justified at the end of the spline. Other string-positioning modifiers than ljust are rjust, above, and below. Lines to be read by pic can be continued by putting a backslash as the rightmost character.
- The last paragraph invokes a macro for dimensioning diagrams.

#### 4.2 The two-terminal elements

Figures 4–9 are tables of the two-terminal elements. Several elements are included more than once to illustrate some of their arguments, which are listed in Section 15.

The first argument of the two-terminal elements, if included, defines the invisible line along which the element is drawn. The other arguments produce variants of the default elements. Thus, for example,

resistor(up\_ 1.25,7)

draws a resistor 1.25 units long up from the current position, with 7 vertices per side. The macro up\_ evaluates to up but also resets the current directional parameters to point up.



Figure 4: Two-terminal elements, showing some variations.



Figure 5: Sources and source-like elements.



Figure 6: Variants of diode(*linespec*, B|D|K|L|LE[R]|P[R]|S|T|V|Z, [R][E]).

Most of the two-terminal elements are oriented; that is, they have a defined polarity. Several element macros include an argument that reverses polarity, but there is also a more general mechanism. The first argument of the macro

reversed('macro name', macro arguments)

is the name of a two-terminal element in quotes, followed by the element arguments. The element is drawn with reversed direction. Thus,

diode(right\_ 0.4); reversed('diode',right\_ 0.4)



Figure 7: The fuse(linespec, A|dA|B|C|D|E|S|HB|HC, wid, ht) and cbreaker(linespec,L|R,D) macros.



Figure 8: Amplifier, delay, and integrator.



Figure 9: The basic switch(*linespec*,L|R,[0|C][D],B) macro and more elabourate dswitch(*linespec*,R,W[ud]B[K]chars) macro, with drawing direction right\_. Setting the second argument to R produces a mirror image with respect to the drawing direction. The macro switch(,,,D) is a wrapper for the comprehensive dswitch macro.

draws two diodes to the right, but the second one points left.

Figure 10 shows some two-terminal elements with arrows or lines overlaid to indicate variability using the macro variable('element', type, angle, length), where type is one of A, P, L, N, with C or S optionally appended to indicate continuous or stepwise variation. Alternatively, this macro can be invoked similarly to the label macros in Section 4.4 by specifying an empty first argument; thus, the following line draws the resistor in Figure 10:

#### resistor(down\_ dimen\_); variable(,uN)

Figure 11 contains arrows for indicating radiation effects. The arrow stems are named A1, A2, and each pair is drawn in a [] block, with the names *Head* and *Tail* defined to aid placement near another device. The second argument specifies absolute angle in degrees (default 135 degrees).



Figure 10: Illustrating variable('element', [A|P|L|[u]N][C|S], angle, length). For example, variable('capacitor(down\_dimen\_)') draws the leftmost capacitor shown above, and variable('resistor(down\_dimen\_)', uN) draws the resistor. The default angle is 45°, regardless of the direction of the element. The array on the right shows the effect of the second argument.



Figure 11: Radiation arrows: em\_arrows(type, angle, length)

#### 4.3 Branch-current arrows

Arrowheads and labels can be added to conductors using basic pic statements. For example, the following line adds a labeled arrowhead at a distance **alpha** along a horizontal line that has just been drawn. Many variations of this are possible:

arrow right arrowht from last line.start+(alpha,0) "\$i\_1\$" above

Macros have been defined to simplify the labelling of two-terminal elements. The macro

b\_current(label, above\_|below\_, In|O[ut], Start|E[nd], frac)

draws an arrow from the start of the last-drawn two-terminal element *frac* of the way toward the body. If the fourth argument is End, the arrow is drawn from the end toward the body. If the third element is Out, the arrow is drawn outward from the body. The first argument is the desired label, of which the default position is the macro above\_, which evaluates to above if the current direction is right or to ljust, below, rjust if the current direction is respectively down, left, up. The label is assumed to be in math mode unless it begins with sprintf or a double quote, in which case it is copied literally. A non-blank second argument specifies the relative position of the label with respect to the arrow, for example below\_, which places the label below with respect to the current direction. Absolute positions, for example below or ljust, also can be specified. Figure 12 illustrates the resulting eight possibilities.



Figure 12: Illustrating b\_current. In all cases the drawing direction is to the right.

For those who prefer a separate arrow to indicate the reference direction for current, the macros larrow(label, ->|<-, dist) and rarrow(label, ->|<-, dist) are provided. The label is placed outside the arrow as shown in Figure 13. The first argument is assumed to be in math mode unless it begins with sprintf or a double quote, in which case the argument is copied literally. The third argument specifies the separation from the element.



Figure 13: The larrow and rarrow macros draw reference-direction arrows adjacent to the element.

#### 4.4 Labels

Macros for labeling two-terminal elements are included:

- llabel( arg1,arg2,arg3 )
- clabel( arg1,arg2,arg3 )
- rlabel( arg1, arg2, arg3 )

dlabel( long,lat,arg1,arg2,arg3 )

The first macro places the three arguments, which are treated as math-mode strings, on the left side of the element block with respect to the current direction: up, down, left, right. The second places the arguments along the centre, and the third along the right side. Thus a simple circuit example with labels is shown in Figure 14. The macro dlabel performs these functions for an obliquely drawn element, placing the three macro arguments at vec\_(-long,lat), vec\_(0,lat), and vec\_(long,lat) respectively relative to the centre of the element. Labels beginning with sprintf or a double quote are copied literally rather than assumed to be in math mode.

```
% 'Loop.m4'
.PS
cct_init
define('dimen_',0.75)
loopwid = 1; loopht = 0.75
  source(up_ loopht); llabel(-,v_s,+)
  resistor(right_ loopwid); llabel(,R,); b_current(i)
  inductor(down_ loopht,W); rlabel(,L,)
  capacitor(left_ loopwid,C); llabel(+,v_C,-); rlabel(,C,)
.PE
```



Figure 14: A loop containing labeled elements, with its source code.

## 5 Other circuit elements

Many basic elements are not two-terminal. These elements are usually enclosed in a block, and contain named locations in the interior. In some cases, an invisible line determining length and direction (but not position) can be specified by the first argument, as for the two-terminal elements. Instead of positioning by the first line, the enclosing block must be placed by using its compass corners, thus: element with corner at position or, when the block contains a predefined location, thus: element with location at position. A few macros are positioned with the first argument; the ground macro, for example: element(at position).

The macro potentiometer (linespec, cycles, fractional pos, length,...), shown in Figure 15, first draws a resistor along the specified line, then adds arrows for taps at fractional positions along the body, with default or specified length. A negative length draws the arrow from the right of the current drawing direction.



Figure 15: Default and multiple-tap potentiometer.

The ground symbol is shown in Figure 16. The first argument specifies position; for example, the two lines shown have identical effect:

move to (1.5,2); ground

ground(at (1.5,2))

The second argument truncates the stem, and the third defines the symbol type. The fourth argument specifies the angle at which the symbol is drawn, with down the default.



Figure 16: The ground( at position, T, N|F|S|L|P|E, U|D|L|R|angle ) macro.

The arguments of the macro antenna( at *position*, T, A|L|T|S|D|P|F, U|D|L|R|angle ) shown in Figure 17 are similar to those of ground.



Figure 17: Antenna symbols, with macro arguments shown above and predefined terminal names below.

Figure 18 illustrates the macro  $\operatorname{opamp}(\operatorname{linespec}, -\operatorname{label}, +\operatorname{label}, \operatorname{size}, [R][P], other com$ mands). The element is enclosed in a block containing the predefined internal locations shown.These locations can be referenced in later commands, for example as 'last [].Out.' The firstargument defines the direction and length of the opamp, but the position is determined either bythe enclosing block of the opamp, or by a construction such as 'opamp with .In1 at Here', whichplaces the internal position In1 at the specified location. There are optional second and third argu $ments for which the defaults are \scriptsize$-$ and \scriptsize$+$ respectively, and the fourth$ argument changes the size of the opamp. The fifth argument adds a power connection, exchangesthe second and third entries, or both. Customizations can be added using the last argument, whichis executed within the [] block after all other elements are drawn.



Figure 18: Operational amplifiers. The P option adds power connections. The second and third arguments can be used to place and rotate arbitrary text at In1 and In2.

Typeset text associated with circuit elements is not rotated by default, as illustrated by the second and third opamps in Figure 18. The opamp labels can be rotated if necessary by using postprocessor commands (for example PSTricks \rput) as second and third arguments.

The code in Figure 19 places an opamp with three connections.



Figure 19: A code fragment invoking the opamp(linespec,-,+,size, [R] [P]) macro.

Figure 20 shows variants of the transformer macro, which has predefined internal locations P1, P2, S1, S2, TP, and TS. The first argument specifies the direction and distance from P1 to P2, with position determined by the enclosing block as for opamps. The second argument places the secondary side of the transformer to the left or right of the drawing direction. The optional third and fifth arguments specifies the number of primary and secondary arcs respectively. If the fourth argument string contains an A, the iron core is omitted, and if it contains a W, wide windings are drawn.

Figure 20: The transformer(linespec,L|R,np,[A][W|L],ns) macro (drawing direction down), showing predefined terminal and centre-tap points.

Figure 21 shows some audio devices, defined in [] blocks, with predefined internal locations as shown. The first argument specifies the device orientation. Thus,

S: speaker(U) with .In2 at Here

places an upward-facing speaker with input In2 at the current location.



Figure 21: Audio components: speaker(U|D|L|R|*degrees*,*size*,*type*), bell, microphone, buzzer, earphone, with their internally named positions and components.

The nport (box specs, nw, nn, ne, ns, space ratio, pin lgth, style) macro is shown in Figure 22. The first argument is a box specification, such as size or fill parameters, or text. The second to fifth arguments specify the number of ports (pin pairs) to be drawn respectively on the west, north, east, and south sides of the box. The end of each pin has a name corresponding to the side, port number and a or b pin, as shown. The sixth argument specifies the ratio of port width to interport space, the seventh is the pin length, and setting the eighth argument to N omits the pin dots. The complete structure is enclosed in a block.

The nterm(box specs, nw, nn, ne, ns, pin lgth, style) macro illustrated in Figure 22 is similar to the nport macro but has one fewer argument, draws single pins instead of pin pairs, and defaults to a 3-terminal box.

Many custom labels or added elements may be required, particularly for 2-ports. These elements can be added using the first argument and the ninth (not mentioned above) of the **nport** macro. For example, the following code adds a pair of labels to the box immediately after drawing it but within the enclosing block:

nport(; '"0"' at Box.w ljust; '" $\infty$ "' at Box.e rjust)



Figure 22: The **nport** macro draws a sequence of pairs of named pins on each side of a box. The pin names are shown. The default is a twoport. The **nterm** macro draws single pins instead of pin pairs.

If this were to be used extensively, then the following custom wrapper would save typing, add the labels, and pass all arguments to **nport**:

```
define('nullor', 'nport('$1'
  {'"${}0$"' at Box.w ljust
    '"$\infty$"' at Box.e rjust},shift($@))')
```

The above example and the related gyrator macro are illustrated in Figure 23.



Figure 23: The nullor example and the gyrator macro are customizations of the nport macro.

A basic winding macro for magnetic-circuit sketches and similar figures is shown in Figure 24. For simplicity, the complete spline is first drawn and then blanked in appropriate places using the background (core) color (lightgray for example, default white).



Figure 24: The winding(L|R, diam, pitch, turns, core wid, core color) macro draws a coil with axis along the current drawing direction. Terminals T1 and T2 are defined. Setting the first argument to R draws a right-hand winding.

Figure 25 shows the macro

contact(0|C, R)

which contains predefined locations P, C, O for the armature and normally closed and normally open terminals. The macro

relay(poles, O|C, R)

defines coil terminals V1, V2 and contact terminals  $P_i$ ,  $C_i$ ,  $O_i$ .



Figure 25: The contact(0|C,R) and relay(poles,0|C,R) macros (default direction right).

Figure 26 shows the variants of bipolar transistor macro

bi\_tr(linespec,L|R,P,E)

which contains predefined internal locations E, B, C. The first argument defines the distance and direction from E to C, with location determined by the enclosing block as for other elements, and the base placed to the left or right of the current drawing direction according to the second argument. Setting the third argument to 'P' creates a PNP device instead of NPN, and setting the fourth to 'E' draws an envelope around the device.



bi\_tr(up\_ dimen\_)

Figure 26: Bipolar transistor variants (current direction upward).

The code fragment example in Figure 27 places a bipolar transistor, connects a ground to the emitter, and connects a resistor to the collector.

S: dot; line left\_ 0.1; up\_ Q1: bi\_tr(,R) with .B at Here ground(at Q1.E) line up 0.1 from Q1.C; resistor(right\_ S.x-Here.x); dot



Figure 27: The bi\_tr(linespec,L|R,P,E) macro.

The bi\_tr and igbt macros are wrappers for the macro bi\_trans(linespec, L|R, chars, E), which draws the components of the transistor according to the characters in its third argument. For example, multiple emitters and collectors can be specified as shown in Figure 28.



Figure 28: The bi\_trans(linespec,L|R, chars,E) macro. The sub-elements are specified by the third argument. The substring En creates multiple emitters E0 to En. Collectors are similar.

A UJT macro with predefined internal locations B1, B2, and E is illustrated in Figure 29, and an SCR macro with predefined internal locations T1, T2, and G is illustrated in Figure 30.



Figure 29: UJT devices, with current drawing direction up.



Figure 30: The thyristor macro, drawing direction down. These are not two-terminal elements, so the *linespec* argument determines direction and length but not position.

Some FETs with predefined internal locations S, D, and G are also included, with similar arguments to those of bi\_tr, as shown in Figure 31. In all cases the first argument is a linespec, and entering R as the second argument orients the G terminal to the right of the current drawing direction. The macros in the top three rows of the figure are wrappers for the general macro mosfet(linespec, R, characters, E). The third argument of this macro is a subset of the characters {BDEFGLQRSTXZ}, each letter corresponding to a diagram component as shown in the bottom row of the figure. Preceding the characters B, G, and S by u or d adds an up or down arrowhead to the pin, and preceding T by d negates the pin. This system allows considerable freedom in choosing or customizing components, as illustrated in Figure 31.



Figure 31: JFET, insulated-gate enhancement and depletion MOSFETS, and simplified versions. These macros are wrappers that invoke the **mosfet** macro as shown in the bottom row. The two lower-right examples show custom devices, the first defined by omitting the substrate connection, and the second defined using a wrapper macro.

The number of possible semiconductor symbols is very large, so these macros must be regarded as prototypes. Often an element is a minor modification of existing elements. For example, the thyristor(linespec, chars) macro illustrated in Figure 30 is derived from the diode and bipolar transistor macros. Some other non-two-terminal macros are dot, which has an optional argument 'at *location*', the line-thickness macros, the fill\_macro, and crossover, which is a useful if archaic method to show non-touching conductor crossovers, as in Figure 32. This figure also illustrates now elements and labels can be colored using the macro

rgbdraw(r, g, b, drawing commands)

where the r, g, b values are in the range 0 to 1 to specify the rgb color. This macro is a wrapper for the following, which may be more convenient if many elements are to be given the same color:

setrgb(r, g, b)
drawing commands

resetrgb

A macro is also provided for colored fills:

rgbfill(r, g, b, drawing commands)

These macros depend heavily on the postprocessor and are intended only for PSTricks, Tikz PGF, MetaPost, and the Postscript output of dpic.



Figure 32: Bipolar transistor circuit, illustrating **crossover** and colored elements.

## 6 Directions, rotations, and macro-level looping

Aside from its block-structure capabilities, looping, and macros, pic has a very useful concept of the current point and current direction, the latter unfortunately limited to up, down, left, right. Objects can be drawn at absolute locations or placed relative to previously drawn objects. These macros need to know the current direction so whenever up, down, left, right are used they should be written respectively as the macros up\_, down\_, left\_, right\_.

To draw circuit objects in other than the standard four directions, the macros  $Point_(degrees)$ ,  $point_(radians)$ , and  $rpoint_(rel linespec)$  re-define the entries m4a\_, m4b\_, m4c\_, m4d\_ of a transformation matrix, which is used for rotations and, potentially, for more general transformations. Thus as shown in Figure 33, 'Point\_(-30); resistor' draws a resistor along a line with slope of -30 degrees, and 'rpoint\_(to Z)' sets the current direction cosines to point from the current location to location Z. Macro vec\_(x,y) evaluates to the position (x,y) rotated as defined by the argument of the previous Point\_, point\_ or rpoint\_ command. The principal device used to define relative locations in the circuit macros is  $rvec_(x,y)$ , which evaluates to position Here +  $vec_(x,y)$ . Thus, line to  $rvec_(x,0)$  draws a line of length x in the current direction.

Figure 33 illustrates that some hand-placement of labels using dlabel may be useful when elements are drawn obliquely. The figure also illustrates that any commas within m4 arguments must be treated specially because the arguments are separated by commas. Argument commas are protected either by parentheses as in inductor(from Cr to Cr+vec\_(elen\_,0)), or by multiple single quotes as in '', '', as necessary. Commas also may be avoided by writing 0.5 between L and T instead of 0.5<L,T>.

Sequential location names such as In1, In2, ... in logic and other diagrams can be generated automatically at the m4 processing stage. The libgen library defines the macro

for\_(start, end, increment, 'actions')

for this and other purposes. Nested loops are allowed and the innermost loop index variable is m4x. The first three arguments must be integers and the *end* value must be reached exactly; for example,

```
% 'Oblique.m4'
.PS
cct_init
Ct:dot; Point_(-60); capacitor(,C); dlabel(0.12,0.12,,,C_3)
Cr:dot; left_; capacitor(,C); dlabel(0.12,0.12,C_2,,)
Cl:dot; down_; capacitor(from Ct to Cl,C); dlabel(0.12,-0.12,,,C_1)
T:dot(at Ct+(0,elen_))
                                                                    R_1
   inductor(from T to Ct); dlabel(0.12,-0.1,,,L_1)
   Point_(-30); inductor(from Cr to Cr+vec_(elen_,0))
      dlabel(0,-0.07,,L_3,)
R:dot
L:dot( at Cl-(R.x-Cr.x,Cr.y-R.y) )
                                                                              C_2
                                                                                       L_3'
                                                                  L_2
   inductor(from L to Cl); dlabel(0,-0.12,,L_2,)
   right_; resistor(from L to R); rlabel(,R_2,)
                                                                            R_2
   resistor(from T to R); dlabel(0,0.15,,R_3,) ; b_current(y,ljust)
   line from L to 0.2<L,T>
   source(to 0.5 between L and T); dlabel(sourcerad_+0.07,0.1,-,,+)
      dlabel(0,sourcerad_+0.07,,u,)
   resistor(to 0.8 between L and T); dlabel(0,0.15,,R_1,)
   line to T
.PE
```

Figure 33: Illustrating elements drawn at oblique angles.

for\_(1,3,2, 'print In' 'm4x') prints locations In1 and In3, but for\_(1,4,2, 'print In' 'm4x') does not terminate since the index takes on values 1, 3, 5, ....

Repetetive actions can also be performed with the libgen macro

Loopover\_('variable', actions, value1, value2, ...)

which evaluates actions for each instance of variable set to value1, value2, ....

## 7 Logic gates

Figure 34 shows the basic logic gates included in library liblog.m4. Gate macros have an optional argument, an integer N from 0 to 16, defining locations In1, ... InN, as illustrated for the NOR gate in the figure. By default N = 2, except for macros NOT\_gate and BUFFER\_gate, which have one input In1 unless they are given a first argument, which is treated as the line specification of a two-terminal element.



Figure 34: Basic logic gates. The input and output locations of a three-input NOR gate are shown. Inputs are negated by including an  $\mathbb{N}$  in the second argument letter sequence. A B in the second argument produces a box shape as shown in the rightmost column, where the second example has AND functionality and the bottom two are examples of exclusive OR functions.

Negated inputs or outputs are marked by circles drawn by the NOT\_circle macro. The name marks the point at the outer edge of the circle and the circle itself has the same name prefixed by N\_. For example, the output circle of a nand gate is named N\_Out and the outermost point of the circle is named Out. The macro IOdefs creates a sequence of named outputs.

Gates are typically not two-terminal elements and are normally drawn horizontally or vertically (although arbitrary directions may be set with e.g. Point\_(degrees)). Each gate is contained in a block of typical height 6\*L\_unit where L\_unit is a macro intended to establish line separation for an imaginary grid on which the elements are superimposed.

Including an N in the second argument character sequence of any gate negates the inputs, and including B in the second argument invokes the general macro  $BOX_gate([P|N]...,[P|N], horiz size, vert size, label)$ , which draws box gates. Thus,  $BOX_gate(PNP,N,,8, \geq 1)$  creates a gate of default width, eight L\_units height, negated output, three inputs with the second negated, and internal label " $\geq 1$ ". If the fifth argument begins with sprintf or a double quote then the argument is copied literally; otherwise it is treated as scriptsize mathematics.

Beyond a default number (6) of inputs, the gates are given wings as illustrated in Figure 35.



Figure 35: Eight-input binary multiplexer circuit with for\_looping in the source, showing a gate with wings.

Input locations retain their positions relative to the gate body regardless of gate orientation, as shown in Figure 36.

```
% 'FF.m4'
.PS S
log_init S
S: NOR_gate
left_
R: NOR_gate at S+(0,-L_unit*(AND_ht+1))
line from S.Out right L_unit*3 then down S.Out.y-R.In2.y then to R.In2
line from R.Out left L_unit*3 then up S.In2.y-R.Out.y then to S.In2
line left 4*L_unit from S.In1 ; "$S$sp_" rjust
line right 4*L_unit from R.In1 ; "sp_$R$" ljust
.PE
```

Figure 36: SR flip-flop.

Figure 37 shows a multiplexer block with variations, and the macro FlipFlop(D|T|RS|JK, *label, boxspec*), which is a wrapper for the more specific FlipFlop6(*label, spec, boxspec*) and FlipFlopJK(*label, spec, boxspec*) macros. Pins on the latter two can be omitted or negated according to their second argument. The second argument of FlipFlop6, for example, contains NQ, Q, CK, S, PR, CLR to include these pins. Preceding any of these with n negates the pin. The substring 1b is included to write labels on the pins. Any other substring applies to the top left pin, with . equating to a blank. Thus, the second argument can be used to customize the flip-flop.



Figure 37: The FlipFlop and Mux macros, with variations.

Customized gates can be defined simply. For example, the following code defines the custom flip-flops in Figure 38.

```
define('customFF', '[ Chip: box wid 10*L_unit ht FF_ht*L_unit
    ifelse('$1',1,'lg_pin(Chip.se+svec_(0,int(FF_ht/4)),lg_bartxt(Q),PinNQ,e)')
    lg_pin(Chip.ne-svec_(0,int(FF_ht/4)),Q,PinQ,e)
    lg_pin(Chip.w,CK,PinCK,wEN)
    lg_pin(Chip.n,PR,PinPR,nN)
    lg_pin(Chip.s,CLR,PinCLR,sN)
    lg_pin(Chip.sw+svec_(0,int(FF_ht/4)),R,PinR,w)
    lg_pin(Chip.nw-svec_(0,int(FF_ht/4)),S,PinS,w) ]')
```

This definition makes use of macros L\_unit and FF\_ht that predifine dimensions and the logic-pin macro lg\_pin(location, printed label, pin name, type). The pin  $\overline{Q}$  is drawn only if the macro argument is 1.



Figure 38: A 5-bit shift register.

For hybrid applications, the dac and adc macros are illustrated in Figure 39. The figure shows the default and predifined internal locations, the number of which can be specified as macro arguments.



Figure 39: The dac(width,height,nIn,nN,nOut,nS) and adc(width,height,nIn,nN,nOut,nS) macros.

A good strategy for drawing complex logic circuits might be summarized as follows:

- Establish the absolute locations of gates and other major components (e.g. chips) relative to a grid of mesh size commensurate with L\_unit, which is an absolute length.
- Draw minor components or blocks relative to the major ones, using parametrized relative distances.
- Draw connecting lines relative to the components and previously drawn lines.
- Write macros for repeated objects.
- Tune the diagram by making absolute locations relative, and by tuning the parameters. Some useful macros for this are the following, which are in units of L\_unit:

AND\_ht, AND\_wd: the height and width of basic AND and OR gates BUF\_ht, BUF\_wd: the height and width of basic buffers N\_diam: the diameter of NOT circles

In addition to the logic gates described here, some experimental IC chip diagrams are included with the distributed example files.

## 8 Element and diagram scaling

There are several issues related to scale changes. You may wish to use millimetres, for example, instead of the default inches. You may wish to change the size of a complete diagram while keeping

the relative proportions of objects within it. You may wish to change the sizes or proportions of individual elements within a diagram. You must take into account that line widths are scaled separately from drawn objects, and that the size of typeset text is independent of the pic language.

The scaling of circuit elements will be described first, then the pic scaling facilities.

#### 8.1 Circuit scaling

The circuit elements all have default dimensions that are multiples of the pic environmental parameter linewid, so changing this parameter changes default element dimensions. The scope of a pic variable is the current block; therefore a sequence such as

```
resistor
```

```
[ linewid = linewid*1.5; resistor ]
resistor
```

produces a string of three resistors, the middle one larger than the other two. Alternatively, you may redefine the default length elen\_ or the body-size parameter dimen\_. For example, adding the line

```
define('dimen_',dimen_*1.2)
```

after the cct\_init line of quick.m4 produces slightly larger element body sizes.

#### 8.2 Pic scaling

There are at least three kinds of graphical elements to be considered:

1. When generating final output after reading the .PE line, pic processors divide distances and sizes by the value of the environmental parameter scale, which is 1 by default. Therefore, the effect of assigning a value to scale at the beginning of the diagram is to change the drawing unit (initially 1 inch) throughout the figure. For example, the file quick.m4 can be modified to use millimetres as follows:

.PS	# Pic input begins with .PS
scale = 25.4	# mm
cct_init	# Set defaults
elen = 19	# Variables are allowed

The default sizes of pic objects are redefined by assigning new values to the environmental parameters arcrad, arrowht, arrowwid, boxht, boxrad, boxwid, circlerad, dashwid, ellipseht, ellipsewid, lineht, linewid, moveht, movewid, textht, and textwid. The ...ht and ...wid parameters refer to the default sizes of vertical and horizontal lines, moves, etc., except for arrowht and arrowwid, which are arrowhead dimensions. The boxrad parameter can be used to put rounded corners on boxes. Assigning a new value to scale also multiplies all of these parameters except arrowht, arrowwid, textht, and textwid by the new value of scale (gpic multiplies them all). Therefore, objects drawn to default sizes are unaffected by changing scale at the beginning of the diagram. To change default sizes, redefine the appropriate parameters explicitly.

The .PS line can be used to scale the entire drawing, regardless of its interior. Thus, for example, the line .PS 100/25.4 scales the entire drawing to a width of 100 mm. Line thickness, text size, and dpic arrowheads are unaffected by this scaling.

If the final picture width exceeds maxpswid, which has a default value of 8.5, then the picture is scaled to this size. Similarly, if the height exceeds maxpsht (default 11), then the picture is scaled to fit. These parameters can be assigned new values as necessary, for example, to accommodate landscape figures.

2. The finished size of typeset text is independent of pic variables, but can be determined as in Section 10. Then, "text" wid x ht y tells pic the size of text, once the printed width x and height y have been found.

3. Line widths are independent of diagram and text scaling, and have to be set explicitly. For example, the assignment linethick = 1.2 sets the default line width to 1.2 pt. The macro linethick\_(points) is also provided, together with default macros thicklines\_ and thinlines\_.

## 9 Writing macros

The m4 language is quite simple and is described in numerous documents such as the original reference [7] or in later manuals [12]. If a new element is required, then modifying and renaming one of the library definitions or simply adding an option to it may suffice. Hints for drawing general two-terminal elements are given in libcct.m4. However, if an element or composite is to be drawn in only one orientation then most of the elaborations used for general two-terminal elements in Section 4 can be dropped.

It may not be necessary to define your own macro if all that is needed is a small addition to an existing element that is defined in an enclosing [] block. The element arguments are expanded in the normal way, and then one argument beyond the normal list is also expanded before exiting the [] block. This process is mentioned with respect to opamps on page 14 and nports on page 15.

A macro is defined using quoted name and replacement text as follows:

define('name', 'replacement text')

After this line is read by the m4 processor, then whenever *name* is encountered as a separate string, it is replaced by its replacement text, which may have multiple lines. The quotation characters are used to defer macro expansion. Macro arguments are referenced inside a macro by number; thus \$1 refers to the first argument.

Custom two-terminal elements can often be defined by writing a wrapper for an existing element. For example, an enclosed thermal switch can be defined as shown in Figure 40.

```
define('thermalsw',
  'dswitch('$1','$2',WDdBT)
  circle rad distance(M4T,last line.c) at last line.c')
```



Figure 40: A custom thermal switch defined from the dswitch macro.

In the following example, two macros are defined to simplify the repeated drawing of a series resistor and series inductor, and the macro tsection defines a subcircuit that is replicated several times to generate Figure 41.

```
% 'Tline.m4'
.PS
cct_init
hgt = elen_*1.5
ewd = dimen_*0.9
define('sresistor', 'resistor(right_ ewd); llabel(,r)')
define('sinductor', 'inductor(right_ ewd,W); llabel(,L)')
define('tsection','sinductor
  { dot; line down_ hgt*0.25; dot
    gpar_( resistor(down_ hgt*0.5); rlabel(,R),
          capacitor(down_ hgt*0.5); rlabel(,C))
    dot; line down_ hgt*0.25; dot }
  sresistor ')
SW: Here
  gap(up_ hgt)
  sresistor
  for i=1 to 4 do { tsection }
  line dotted right_ dimen_/2
  tsection
  gap(down_ hgt)
```



Figure 41: A lumped model of a transmission line, illustrating the use of custom macros.

## 10 Interaction with LATEX

The sizes of typeset labels and other  $T_EX$  boxes are generally unknown prior to processing the diagram by  $LAT_EX$ . Although they are not needed for many circuit diagrams, these sizes may be required explicitly for calculations or implicitly for determining the diagram bounding box. For example, the text sizes in the following example affect the total size of the diagram:

```
.PS
B: box
"Left text" at B.w rjust
"Right text: $x^2$" at B.e ljust
.PE
```

The pic interpreter cannot know the dimensions of the text to the left and right of the box, and the diagram is generated using default text dimensions. One solution is to measure the text sizes by hand and include them literally, thus:

"Left text" wid 38.47pt\_\_ ht 7pt\_\_ at B.w rjust but this is tedious.

A better solution to this problem is to process the diagram twice. The diagram source is processed as usual by m4 and a pic processor, and the main document source is  $\text{ET}_{\text{E}}$ Xed to input the diagram and format the text, and also to write the required dimensions into a supplementary file. Then the diagram source is processed again, reading the required dimensions from the supplementary file and producing a diagram ready for final  $\text{ET}_{\text{E}}$ Xing. This hackery is summarized below, with an example in Figure 42.

- Put \usepackage{boxdims} into the document source.
- Insert the following at the beginning of the diagram source, where *jobname* is the name of the main LATEX file: sinclude(*jobname.dim*) s\_init(*unique name*)
- Use the macro s\_box(*text*) to produce typeset text of known size as shown in Figure 42; alternatively, invoke the macros \boxdims and boxdim described later.

The macro **s\_box**(*text*) evaluates initially to

"\boxdims{name}{text}" wid boxdim(name,w) ht boxdim(name,v)

On the second pass, this is equivalent to

"text" wid x ht y

where x and y are the typeset dimensions of the  $IAT_EX$  input text. If s\_box is given two or more arguments as in Figure 42 then they are processed by sprintf.

.PS		
sinclude(CMman.dim)		
s_init(stringdims)	:	:
B: box	Left text	Right text: $x^2$
s_box(Left text) at B.w rjust		
s_box(Right text: \$x^%g\$,2) at B.e ljust	·L	
.PE		

Figure 42: The macro s\_box sets string dimensions automatically when processed twice. If two or more arguments are given to s\_box, they are passed through sprintf. The dots show the figure bounding box.

The argument of s\_init, which should be unique within jobname.dim, is used to generate a unique \boxdims first argument for each invocation of s\_box in the current file. If s\_init has been omitted, the symbols "!!" are inserted into the text as a warning. Be sure to quote any commas in the arguments. Since the first argument of s\_box is IATEX source, make a rule of quoting it to avoid comma and name-clash problems. For convenience, the macros s\_ht, s\_wd, and s\_dp evaluate to the dimensions of the most recent s\_box string or to the dimensions of their argument names, if present.

The file **boxdims.sty** distributed with this package should be installed where LATEX can find it. The essential idea is to define a two-argument LATEX macro **boxdims** that writes out definitions for the width, height and depth of its typeset second argument into file *jobname.dim*, where *jobname* is the name of the main source file. The first argument of **boxdims** is used to construct unique symbolic names for these dimensions. Thus, the line

box "\boxdims{Q}{\Huge Hi there!}"

has the same effect as

box "\Huge Hi there!"

except that the line

define('Q\_w',77.6077pt\_)define('Q\_h',17.27779pt\_)define('Q\_d',0.0pt\_)dnl is written into file *jobname.dim* (and the numerical values depend on the current font). These definitions are required by the boxdim macro described below.

The LATEX macro

\boxdimfile{dimension file}

is used to specify an alternative to *jobname.dim* as the dimension file to be written. This simplifies cases where *jobname* is not known in advance or where an absolute path name is required.

Another simplification is available. Instead of the sinclude(dimension file) line above, the dimension file can be read by m4 before reprocessing the source for the second time:

m4 library files dimension file diagram source file ...

Objects can be tailored to their attached text by invoking \boxdims and boxdim explicitly. The small source file in Figure 43, for example, produces the box in the figure.

```
% 'eboxdims.m4'
.PS
sinclude(CMman.dim) # The main input file is CMman.tex
box fill_(0.9) wid boxdim(Q,w) + 5pt__ ht boxdim(Q,v) + 5pt__ \
    "\boxdims{Q}{\large$\displaystyle\int_0^T e^{tA}\,dt$}"
.PE
```



Figure 43: Fitting a box to typeset text.

The figure is processed twice, as described previously. The line sinclude(jobname.dim) reads the named file if it exists. The macro boxdim(name,suffix,default) from libgen.m4 expands the expression boxdim(Q,w) to the value of  $Q_w$  if it is defined, else to its third argument if defined, else to 0, the latter two cases applying if jobname.dim doesn't exist yet. The values of boxdim(Q,h) and boxdim(Q,d) are similarly defined and, for convenience, boxdim(Q,v) evaluates to the sum of these. Macro  $pt_{-}$  is defined as \*scale/72.27 in libgen.m4, to convert points to drawing coordinates. Sometimes a label needs a plain background in order to blank out previously drawn components overlapped by the label, as shown on the left of Figure 44. The technique illustrated in Figure 43

Wood chips



Figure 44: Illustrating the f\_box macro.

is automated by the macro f\_box(boxspecs, label arguments). For the special case of only one argument, e.g., f\_box(Wood chips), this macro simply overwrites the label on a white box of identical size. Otherwise, the first argument specifes the box characteristics (except for size), and the macro evaluates to

box boxspecs s\_box(label arguments).

For example, the result of the following command is shown on the right of Figure 44.

f\_box(color "lightgray" thickness 2 rad 2pt\_\_,"\huge\$n^{%g}\$",4-1)

More tricks can be played. The example

Picture: s\_box('\includegraphics{file.eps}') with .sw at location

shows a nice way of including eps graphics in a diagram. The included picture (named Picture in the example) has known position and dimensions, which can be used to add vector graphics or text to the picture. To aid in overlaying objects, the macro boxcoord(object name, x-fraction, y-fraction) evaluates to a position, with boxcoord(object name, 0,0) at the lower left corner of the object, and boxcoord(object name, 1,1) at its upper right.

## 11 PSTricks and other tricks

This section applies only to a pic processor (dpic) that is capable of producing output compatible with PSTricks, Tikz PGF, or, in principle, other graphics postprocessors.

By using command lines, or simply by inserting LATEX graphics directives along with strings to be formatted, one can mix arbitrary PSTricks (or other) commands with m4 input to create complicated effects.

Some commonly required effects are particularly simple. For example, the rotation of text by PSTricks postprocessing is illustrated by the file

```
% 'Axes.m4'
.PS
arrow right 0.7 "'$x$-axis'" below
arrow up 0.7 from 1st arrow.start "'\rput[B]{90}(0,0){$y$-axis}'" rjust
.PE
```

which contains both horizontal text and text rotated 90° along the vertical line. This rotation of text is also implemented by the macro rs\_box, which is similar to s\_box but rotates its text argument by 90°, a default angle that can be changed by preceding invocation with define('text\_ang', degrees). The rs\_box macro requires either PSTricks or Tikz PGF.

Another common requirement is the filling of arbitrary shapes, as illustrated by the following lines within a .m4 file:

```
command "'\pscustom[fillstyle=solid,fillcolor=lightgray]{'"
drawing commands for an arbitrary closed curve
command "'}%'"
```

For colour printing or viewing, arbitrary colours can be chosen, as described in the PSTricks manual. PSTricks parameters can be set by inserting the line

```
command "'\psset{option=value, ...}'"
```

in the drawing commands or by using the macro psset\_(PSTricks options).

The macros shade (gray value, closed line specs) and rgbfill (red value, green value, blue value, closed line specs) can be invoked to accomplish the same effect as the above fill example, but are not confined to use only with PSTricks.

Since arbitrary  $IAT_EX$  can be output, either in ordinary strings or by use of command output, then complex examples such as found in reference [4] can be included, for example. The complications are twofold:  $IAT_EX$  and dpic may not know the dimensions of the formatted result, and the code is generally unique to the postprocessor. Where postprocessors are capable of equivalent results, then macros such as rs\_box, shade, and rgbfill mentioned previously may hide code differences.

## 12 Web documents, pdf, and alternative output formats

Circuit diagrams contain graphics and symbols, and the issues related to web publishing are similar to those for other mathematical documents. Here the important factor is that gpic -t generates output containing tpic \special commands, which must be converted to the desired output, whereas dpic can generate several alternative formats, as shown in Figure 45. One of the easiest methods for producing web documents is to generate postscript as usual and to convert the result to pdf format with Adobe Distiller® or equivalent.



Figure 45: Output formats produced by gpic -t and dpic.

PDFlatex produces pdf without first creating a postscript file but does not handle tpic \specials, so dpic must be installed.

Most PDFLatex distributions are not directly compatible with PSTricks, but the Tikz PGF output of dpic is compatible with both  $IAT_EX$  and PDFLatex. Several alternative dpic output formats such as mfpic and MetaPost also work well. To test MetaPost, create a file filename.mp containing appropriate header lines, for example:

```
verbatimtex
\documentclass[11pt]{article}
\usepackage{times,boxdims,graphicx}
\boxdimfile{tmp.dim}
\begin{document} etex
```

Then append one or more diagrams by using the equivalent of

m4 <path>mpost.m4 library files diagram.m4 | dpic -s >> filename.mp

The command "mpost --tex=latex filename.mp end" processes this file, formatting the diagram text by creating a temporary .tex file, LATEXing it, and recovering the .dvi output to create filename.1 and other files. If the boxdims macros are being invoked, this process must be repeated to handle formatted text correctly as described in Section 10. In this case, either put sinclude(tmp.dim) in the diagram .m4 source or read the .dim file at the second invocation of m4 as follows:

m4 path>mpost.m4 library files tmp.dim diagram.m4 | dpic -s >> filename.mp

On some operating systems, the absolute path name for tmp.dim has to be used to ensure that the correct dimension file is written and read. This distribution includes a Makefile that simplifies the process; otherwise a script can automate it.

Having produced filename.1, rename it to filename.mps and, voilà, you can now run PDFlatex on a .tex source that includes the diagram using \includegraphics{filename.mps} in the usual way.

The dpic processor is capable of other output formats, as illustrated in Figure 45 and in example files included with the distribution. The  $\text{ET}_{\text{EX}}$  drawing commands alone or with eepic or pict2e extensions are suitable only for simple diagrams.

## 13 Developer's notes

Years ago in the course of writing a book, I took a few days off to write a pic-like interpreter (dpic) to automate the tedious coordinate calculations required by  $IAT_EX$  picture objects. The macros in this distribution and the interpreter are the result of that effort, drawings I have had to produce since, and suggestions received from other people. The interpreter has been upgraded over time to generate mfpic, MetaPost [6], raw Postscript, Postscriptwith **psfrag** tags, and PSTricks output, the latter my preference because of its quality and flexibility, including facilities for colour and rotations, together with simple font selection. In addition, xfig-compatible output has been added and, most recently, TikZ PGF output, which combines the simplicity of PSTricks with PDFlatex compatibility. Instead of pic macros, I preferred the equally simple but more powerful m4 macro processor, and therefore m4 is required here, although dpic now supports pic-like macros. Free versions of m4 are available for Unix, Windows, and other operating systems.

If starting over today would I not just use one of the other drawing packages available these days? It would depend on the context, but pic remains a good choice for line drawings since it is easy to learn and read but powerful enough for coding the geometrical calculations required for precise component sizing and placement. However, the main value of this distribution is in the macros, which have been developed and refined over nearly two decades. Some of them have become less readable as more options and flexibility have been added, and if starting over today, perhaps I would change some details. No choice of tool is without compromise, and producing good graphics seems to be time-consuming, no matter how it is done.

The dpic interpreter has several output-format options that may be useful. The eepicemu and pict2e extensions of the primitive IATEX picture objects are supported. The mfpic output allows the production of Metafont alphabets of circuit elements or other graphics, thereby essentially removing dependence on device drivers, but with the complication of treating every alphabetic component as a TEX box. The xfig output allows elements to be precisely defined with dpic and interactively placed with xfig. Dpic will also ouput low-level MetaPost or Postscript code, so that diagrams defined using pic can be manipulated and combined with others. The Postscript output is compatible with CorelDraw®, and by extension to Adobe Illustrator®. With raw Postscript output the user is responsible for ensuring that the correct fonts are provided and for formatting labels.

Many thanks to the people who have sent comments, questions, and, occasionally, bug fixes for the macros. What began as a tool for my own work grew into a hobby that has persisted, thanks to your help and advice.

## 14 Bugs

The distributed macros are not written for maximum robustness. Arguments could be entered in a key-value style (for example, resistor(up\_elen\_,style=N;cycles=8) instead of by positional parameters. Macro arguments could be tested for correctness and explanatory error messages could be written as necessary, but that would make the macros more difficult to read and to write. You will have to read them when unexpected results are obtained or when you wish to modify them.

In response to suggestions, some of the macros have been modified to allow easier customization to forms not originally anticipated, but these modifications are not complete. Here are some hints, gleaned from experience and from comments I have received.

1. Misconfiguration: One of the following configuration files *must* be read by m4 before any of the other files, depending on the required form of pic output: gpic.m4, pstricks.m4, postscript.m4, pgf.m4, mpost.m4, mfpic.m4, or xfig.m4. The package default is to read gpic.m4. The processor options must be set correspondly, gpic -t for gpic.m4 and, most often, dpic -p or dpic -g when dpic is employed. For example, the pipeline for PSTricks output from file circuit.m4 is

m4 <path>pstricks.m4 <path>libcct.m4 circuit.m4 | dpic -p > circuit.tex

but for Tikz PGF processing, the configuration file and dpic option have to be changed:

```
m4 <path>pgf.m4 <path>libcct.m4 circuit.m4 | dpic -g > circuit.tex
```

Any non-default configuration file must be processed explicitly as illustrated above. To redefine the default behaviour, change the **include** statements near the top of the libraries. The top-level makefile automates these changes.

2. Initialization: If the first element macro evaluated is not two-terminal or is within a Pic block, then later macros evaluated outside the block may produce the error message

there is no variable 'rp\_ang'

because **rp\_ang** is not defined in the outermost scope of the diagram. To cure this problem, make sure that the line

cct\_init

appears immediately after the .PS line or prior to the first block. It is entirely permissible to modify cct\_init to include customized diagram initializations such as the thicklines\_ statement. For completeness, macros gen\_init, log\_init, darrow\_init are also provided for cases where the circuit library is not needed.

3. Pic objects versus macros: A common error is to write something like

```
line from A to B; resistor from B to C when it should be
```

line from A to B; resistor(from B to C)

This error is caused by an unfortunate inconsistency between the linear pic objects and the way m4 passes macro arguments.

4. **Commas:** Macro arguments are separated by commas, so any comma that is part of an argument must be protected by parentheses or quotes. Thus,

```
shadebox(box with .n at w,h)
produces an error, whereas
shadebox(box with .n at w','h)
and
shadebox(box with .n at (w,h))
do not.
```

5. **Default directions and lengths:** The *linespec* argument of element macros requires both a direction and a length, and if either is omitted, a default value is used. Writing

source(up\_)

draws a source up a distance equal to the current lineht value, which may cause confusion. Writing

source(0.5)

draws a source of length 0.5 units in the current pic default direction, which is one of right, left, up, or down. It is usually better to specify both the direction and length of an element, thus:

source(up\_ elen\_).

The effect of a *linespec* argument is independent of any direction set using the Point\_ or similar macros. To draw an element at an obtuse angle (see Section 6) try, for example,

Point\_(45); source(to rvec\_(0.5,0))

6. Quotes: Single quote characters are stripped in pairs by m4, so the string

```
"''inverse''"
```

will be typeset as if it were

"'inverse'".

The cure is to add single quotes.

The only subtlety required in writing m4 macros is deciding when to quote arguments. In the context of circuits it seemed best to assume that macro arguments would not be protected by quotes at the level of macro invocation, but should be quoted inside each macro. There may be cases where this rule is not optimal or where the quotes could be omitted.

7. Dollar signs: The *i*-th argument of an m4 macro is i, where *i* is an integer, so the following construction can cause an error when it is part of a macro,

"\$0\$" rjust below

since 0 expands to the name of the macro itself. To avoid this problem, put the string in quotes or write "\$',0\$".

8. Name conflicts: Using the name of a macro as part of a comment or string is a simple and common error. Thus,

arrow right "\$\dot x\$" above

produces an error message because dot is a macro name. Macro expansion can be avoided by adding quotes, as follows:

arrow right '"\$\dot x\$"' above

Library macros intended only for internal use have names that begin with m4 to avoid name clashes, but in addition, a good rule is to quote all LATEX in the diagram input.

If extensive use of strings that conflict with macro names is required, then one possibility is to replace the strings by macros to be expanded by  $ext{ETEX}$ , for example the diagram

.PS

```
box "\stringA"
.PE
```

with the LaTeX macro

\newcommand{\stringA}{

Circuit containing planar inductor and capacitor}

 Current direction: Some macros, particularly those for labels, do unexpected things if care is not taken to preset the current direction using macros right\_, left\_, up\_, down\_, or rpoint\_(.). Thus for two-terminal macros it is good practice to write, e.g.

```
resistor(up_ from A to B); rlabel(,R_1)
```

rather than

resistor(from A to B); rlabel(,R\_1),

which produce different results if the last-defined drawing direction is not up. It might be possible to change the label macros to avoid this problem without sacrificing ease of use. 10. Position of elements that are not 2-terminal: The *linespec* argument of elements defined in [] blocks must be understood as defining a direction and length, but not the position of the resulting block. In the pic language, objects inside these brackets are placed by default *as if the block were a box.* Place the element by its compass corners or defined interior points as described in the first paragraph of Section 5 on page 13, for example

igbt(up\_ elen\_) with .E at (1,0)

- 11. **Pic error messages:** Some errors are detected only after scanning beyond the end of the line containing the error. The semicolon is a logical line end, so putting a semicolon at the end of lines may assist in locating bugs.
- 12. Scaling: Pic and these macros provide several ways to scale diagrams and elements within them, but subtle unanticipated effects may appear. The line .PS x provides a convenient way to force the finished diagram to width x. However if gpic is the pic processor then all scaled parameters are affected, including those for arrowheads and text parameters, which may not be the desired result. A good general rule is to use the scale parameter for global scaling unless the primary objective is to specify overall dimensions.
- 13. Buffer overflow: For some m4 implementations, the error message pushed back more than 4096 chars results from expanding large macros or macro arguments, and can be avoided by enlarging the buffer. For example, the option -B16000 enlarges the buffer size to 16000 bytes. However, this error message could also result from a syntax error.

## 15 List of macros

The following table lists the macros in libraries darrow.m4, libcct.m4, liblog.m4, libgen.m4, and files gpic.m4, mfpic.m4, and pstricks.m4. Some of the sources in the examples directory contain additional macros, such as for flowcharts, Boolean logic, and binary trees.

Internal macros defined within the libraries begin with the characters m4 or M4 and, for the most part, are not listed here.

The library in which each macro is found is given, and a brief description.

$\log$	basic 'and' gate, 2 or $n$ inputs; N=negated input
log	general AND gate: $n=$ number of inputs $(0 \le n \le 16)$ ; chars: B=base and straight sides; A=Arc; [N]NE,[N]SE,[N]I,[N]N,[N]S=inputs or circles; [N]O=output; C=center
$\log$	height of basic 'and' and 'or' gates in L_units
$\log$	width of basic 'and' and 'or' gates in L_units
ht,label)	
$\log$	output=[P N], inputs=[P N], sizes swid and sht in
	L_units
$\log$	basic buffer, 1 input or as a 2-terminal element,
	N=negated input
]*,[N P]	*,[N P]*)
log	general buffer, <i>chars:</i> T=triangle, [N]0=output location Out (NO draws circle N_Out); [N]I, [N]N, [N]S, [N]NE, [N]SE input locations; C=centre location. Args 4-6 allow alternative definitions of respective In, NE, and SE argument sequences
$\log$	basic buffer gate height in L_units
$\log$	basic buffer gate width in L_units
gen	cosine function, <i>integer</i> degrees
	log log log sht,label) log ]*,[N P] log log log log gen

Cosine( amplitude, freq, time, phase ) function  $a \times \cos(\omega t + \phi)$ gen Darlington(linespec,L|R,P) left or right, N- or P-type bipolar Darlington pair,  $\operatorname{cct}$ internal locations E, B, C E\_ gen the constant eEquidist3(Pos1, Pos2, Pos3, Result) Calculates location named Result equidistant from the gen first three positions, i.e. the centre of the circle passing through the three positions FF\_ht  $\operatorname{cct}$ flipflop height parameter in L\_units FF\_wid flipflop width parameter in L\_units  $\operatorname{cct}$ vector projected on current view plane with top face of Fector(x1,y1,z1,x2,y2,z2) 3D 3-dimensional arrowhead normal to x2,y2,z2 FlipFlop(D|T|RS|JK, label, boxspec) flip-flops, boxspec=e.g. ht x wid y log FlipFlop6(label, spec, boxspec) log 6-input flip-flops, spec=[[n]NQ][[n]Q][[n]CK][[n]PR][lb] [[n]CLR][[n]S][[n].|D|T|R] to include and negate pins, 1b to print labels FlipFlopJK(label, spec, boxspec) JK flip-flop, spec similar to above log G\_hht gate half-height in L\_units log HOMELIB\_ all directory containing libraries H\_ht log hysteresis symbol dimension in L\_units corrected (old) gpic int() function Int\_ gen IOdefs(linespec, label, [P|N]\*,L|R) Define locations label1, ... labeln along the line; P =log label only; N=with NOT\_circle; R=circle to right of current direction Intersect\_(Name1, Name2) intersection of two named lines gen logic-gate hysteresis symbol LH\_symbol(U|D|L|R|degrees) log Loopover\_('variable', actions, value1, value2, ...) gen Repeat actions with variable set successively to value1, value $2, \ldots$ LT\_symbol(U|D|L|R|degrees) log logic-gate triangle symbol L\_unit logic-element grid size log Max(arg, arg, ...) Max of an arbitrary number of inputs gen Min(arg, arg, ...) Min of an arbitrary number of inputs gen binary multiplexer, n inputs, L reverses pin numbers, T Mux(n, label, [L] [T]) gen puts Sel pin to top Mux\_ht Mux height parameter in L\_units  $\operatorname{cct}$ Mux\_wid Mux width parameter in L\_units  $\operatorname{cct}$ max number of gate inputs without wings Mx\_pins log  $NAND_gate(n, N)$ 'nand' gate, 2 or n inputs; N=negated input log NOR\_gate(n,N) 'nor' gate, 2 or n inputs; N=negated input log NOT\_circle log 'not' circle

NOT_gate(linespec,N)	$\log$	'not' gate, 1 input or as a 2-terminal element, N=negated input
NOT_rad	log	'not' radius in absolute units
NXOR_gate( $n$ ,N)	log	'nxor' gate, 2 or $n$ inputs; N=negated input
N_diam	log	diameter of 'not' circles in L_units
N_rad	log	radius of 'not' circles in L_units
OR_gate(n,N)	log	'or' gate, 2 or <i>n</i> inputs; N=negated input
OR_gen(n, chars, [wid, [ht]])	log	general OR gate: $n$ =number of inputs ( $0 \le n \le 16$ ); chars: B=base and straight sides; A=Arcs; [N]NE,[N]SE,[N]I,[N]N,[N]S=inputs or circles; [N]P=XOR arc; [N]O=output; C=center
OR_rad	$\log$	radius of OR input face in L_units
Point_(integer)	gen	sets direction cosines in degrees
Rect_(radius, angle)	gen	(deg) polar-to-rectangular conversion
Sin(integer)	gen	sine function, <i>integer</i> degrees
View3D	3D	The view vector (triple) defined by setview(azim, elev). The project macro projects onto the plane perpendicular to this vector
Vperp(position name, position	name)	
	gen	unit-vector pair CCW-perpendicular to line joining two named positions
$XOR_gate(n,N)$	$\log$	'xor' gate, 2 or $n$ inputs; N=negated input
XOR_off	$\log$	XOR and NXOR offset of input face
above_	$\operatorname{gen}$	string position above relative to current direction
abs_(number)	$\operatorname{gen}$	absolute value function
<pre>adc(width,height,nIn,nN,nOut amp(linespec.size)</pre>	,nS) cct	ADC with defined width, height, and number of inputs $Ini$ , top terminals $Ni$ , ouputs $Outi$ , and bottom terminals $Si$ amplifier
along (linear object name)	gen	short for between name start and name end
antenna (at location, T. ALL)		F. UDLIB/degrees)
, _, _, _, _,	cct	antenna, without stem for nonblank 2nd arg; A=aerial, L=loop, T=triangle, S=diamond, D=dipole, P=phased, F=fork; up, down, left, right, or angle from horizontal (default -90)
arca(chord linespec, ccw cw,	radius, gen	modifiers) arc with acute angle (obtuse if radius is negative)
arcd(center, radius, start degre	ees,end gen	degrees) arc definition (see arcr), angles in degrees
arcr(center, radius, start angle,	end ang	le)
	$\operatorname{gen}$	arc definition, e.g., arcr(A,r,0,pi_/2) cw ->
arcto(position 1, position 2, rac	<i>lius</i> ,[da gen	<pre>shed dotted]) line toward position 1 with rounded corner toward position 2</pre>
<pre>arrowline(linespec)</pre>	$\operatorname{cct}$	line (dotted, dashed permissible) with centred arrowhead
b_	$\operatorname{gen}$	blue color value
b_current(label, pos, In Out, S	tart En	d, frac)

	$\operatorname{cct}$	labelled branch-current arrow to <i>frac</i> between branch end and body
<pre>battery(linespec,n,R)</pre>	$\operatorname{cct}$	n-cell battery: default 1 cell, R=reversed polarity
beginshade(gray value)	gen	<pre>begin gray shading, see shade e.g., beginshade(.5); closed line specs; endshade</pre>
bell( U D L R degrees, size)	$\operatorname{cct}$	bell, In1 to In3 defined
below_	$\operatorname{gen}$	string position relative to current direction
bi_tr( <i>linespec</i> ,L R,P,E)	$\operatorname{cct}$	left or right, N- or P-type bipolar transistor, without or with envelope
bi_trans(linespec,L R,chars,E	)	
	cct	<ul> <li>bipolar transistor, core left or right; chars: BU=bulk line,</li> <li>B=base line and label, S=Schottky base hooks,</li> <li>uEn dEn=emitters E0 to En, uE dE=single emitter,</li> <li>Cn uCn dCn=collectors C0 to Cn; u or d add an arrow,</li> <li>C=single collector; u or d add an arrow, G=gate line and location, H=gate line; L=L-gate line and location,</li> <li>[d]D=named parallel diode, d=dotted connection,</li> <li>[u]T=thyristor trigger line; arg 4 = E: envelope</li> </ul>
boxcoord(planar obj, x fraction	y fracti	ion)
	gen	internal point in a planar object
boxdim(name,h w d v,default)	) gen	evaluate, e.g. $name_w$ if defined, else <i>default</i> if given, else 0 v gives sum of d and h values
bp	$\operatorname{gen}$	big-point-size factor, in scaled inches, $(*scale/72)$
<pre>bswitch(linespec, [L R])</pre>	$\operatorname{cct}$	pushbutton switch
<pre>buzzer( U D L R degrees, si</pre>	.ze,[C])	human In 1 to In 2 defende Commend
- f-+ (linggroup I   D D)	cct	left on right, plain on possible rin simplified MOSEET
c_ret(mespec,L R,P)	cct	consistent of right, plain of negated pin simplified MOSFET
capacitor(mespec, char[+], k)	CCU	E=polarized boxed plates, K=filled boxed plates, P=alternate polarized; + adds a polarity sign; arg3: R=reversed polarity
cbreaker( <i>linespec</i> , L R, D)	$\operatorname{cct}$	circuit breaker to left or right, $\mathtt{D}{=}\mathrm{dotted}$
cct_init	$\operatorname{cct}$	initialize circuit-diagram environment
centerline_(linespec, thickness	gen gen	minimum long dash len, short dash len, gap len Technical drawing centerline
cintersect(Pos1, Pos2, rad1, r	ad2, [R]	
	gen	Upper (lower if $arg5=R$ ) intersection of circles at $Pos1$ and $Pos2$ , radius $rad1$ and $rad2$
<pre>clabel(label, label, label)</pre>	$\operatorname{cct}$	centre triple label
consource( <i>linespec</i> ,V I v i,R	)cct	voltage or current controlled source with alternate forms; $R{=}\mathrm{reversed}$ polarity
contact(0 C,R)	$\operatorname{cct}$	single-pole contact: default double pole or normally open or closed, $R{=}oriented$ right (default left)
contline(line)	gen	evaluates to continue if processor is dpic, otherwise to first arg (default line)
cosd(arg)	gen	cosine of an expression in degrees
cross(at location)	gen	plots a small cross
cross3D(x1,y1,z1,x2,y2,z2)	3D	cross product of two triples
crossover( <i>linespec</i> , L R, Lin	e1,	)

	$\operatorname{cct}$	line jumping left or right over named lines
crosswd_	gen	cross dimension
csdim_	$\operatorname{cct}$	controlled-source width
dac(width,height,nIn,nN,nOut	,nS)	
	cct	DAC with defined width, height, and number of inputs $Ini$ , top terminals $Ni$ , ouputs $Outi$ , and bottom terminals $Si$
d_fet( <i>linespec</i> ,L K,P,S,E S)	cct	simplified, without or with envelope or thick channel
dabove(at location)	darrow	above (displaced dlinewid/2)
<pre>darrow(linespec, t,t,width,as</pre>	rrowhd w darrow	vd, arrowhd ht, <- or <-   or  ) double arrow, truncated at beginning or end, specified sizes, reversed arrowhead or closed stem
darrow_init	darrow	initialize darrow drawing parameters
dashline(linespec,thickness co	olor <->, gen	dash len, gap len,G) dashed line with dash at end (G ends with gap)
dbelow(at <i>location</i> )	darrow	below (displaced dlinewid/2)
dcosine3D(i,x,y,z)	3D	extract i-th entry of triple x,y,z
def_bisect	gen	defines the pic procedure bisect (func, xmin, xmax, eps, result ) that finds a root of func(arg, value) to precision eps in the interval (xmin, xmax) by the method of bisection
delay(linespec,size)	$\operatorname{cct}$	delay element
delay_rad_	$\operatorname{cct}$	delay radius
deleminit_	darrow	sets drawing direction for dlines
dend(at location)	darrow	close (or start) double line
diff3D(x1,y1,z1,x2,y2,z2)	3D	difference of two triples
diff_(a,b)	gen	difference function
dimen_	$\operatorname{cct}$	size parameter for circuit elements
dimension_(linespec, offset, labo	el, D H  gen	W blank width, tic offset, arrowhead ) macro for dimensioning diagrams; arrowhead=->   <-
diode( <i>linespec</i> ,B CR D K L LE	[R]   P [R]	]  S T V v Z, [R] [E]) diode: B=bi-directional, CR=current regulator, D=diac, K=open form, L=open form with centre line, LED[R]=LED [right], P[R]=photodiode [right], S=Schottky, T=tunnel, V=varicap, v=varicap (curved plate), Z=zener; arg 4: R=reversed polarity, E=enclosure
dir_	darrow	used for temporary storage of direction by darrow macros
distance(Position 1, Position)	2)	
	gen	distance between named positions
direction_(U D L R  <i>degrees</i> ,	default) gen	sets current direction up, down, left, right, or angle in degrees
distance(position, position)	gen	distance between positions
dlabel(long, lat, label, label, lab	bel) cct	general triple label
dleft	darrow	double line left turn

dline(linespec,t,t,width, |-| or -| or |-)

	darrow	double line, truncated by half width at either end, closed
dlinewid	darrow	width of double lines
dn_	gen	down with respect to current direction
dljust(at location)	darrow	ljust (displaced dlinewid/2)
dn_	gen	sets down relative to current-direction
dna_	cct	characters that determine which components are drawn
dnm_	$\operatorname{cct}$	similar to dna_
dot(at location, radius, fill)	gen	filled circle (third arg= gray value: 0=black, 1=white)
dot3D(x1,y1,z1,x2,y2,z2)	3D	dot product of two triples
dotrad_	gen	dot radius
down_	gen	sets current direction to down
dright	darrow	double arrow right turn
drjust(at location)	darrow	rjust (displaced dlinewid/2)
dswitch( <i>linespec</i> ,L R,W[ud]B[H	(] chars)	
dtee([[]]])	cct	SPST switch left or right, W=baseline, B=contact blade, dB=contact blade to the right of drawing direction, K=vertical closing contact line, C = external operating mechanism, D = circle at contact and hinge, (dD = hinge only, uD = contact only) E = emergency button, EL = early close (or late open), LE = late close (or early open), F = fused, H = time delay closing, uH = time delay opening, HH = time delay opening and closing, K = vertical closing contact, L = limit, M = maintained (latched), MM = momentary contact on make, MR = momentary contact on release, MMR = momentary contact on make and release, O = hand operation button, P = pushbutton, T = thermal control linkage, Y = pull switch, Z = turn switch
dtee([L R])	darrow	(default) back along current direction
dtor_	gen	degrees to radians conversion constant
dturn(degrees ccw)	$\operatorname{darrow}$	turn dline arg1 degrees left (ccw)
e_	gen	.e relative to current direction
e_fet(linespec,L R,P,S,E S)	$\operatorname{cct}$	left or right, N or P enhancement MOSFET, normal or simplified, without or with envelope or thick channel
earphone( U D L R degrees,	size)	
	cct	earphone, In1 to In3 defined
ebox(linespec, length, ht, fill val	ue)	two terminal has element with adjustable dimensions
	cct	and fill value 0 (black) to 1 (white)
elchop(E,A)	gen	chop for ellipses: evaluates to chop $r$ where $r$ is the distance from the centre of ellipse E to the intersection of E with a line to location A; e.g., line from A to E elchop(E,A)
<pre>eleminit_(linespec)</pre>	$\operatorname{cct}$	internal line initialization
elen_	$\operatorname{cct}$	default element length
<pre>em_arrows([N I E][D], angle, le</pre>	ngth)	

	$\operatorname{cct}$	radiation arrows, N=nonionizing, I=ionizing, E=simple; D=dot
endshade	gen	end gray shading, see beginshade
expe	gen	exponential, base $e$
f_box(boxspecs,text,expr1,)	gen	like <b>s_box</b> but the text is overlaid on a box of identical size. If there is only one argument then the default box is invisible and filed white
fill_(number)	gen	fill macro, 0=black, 1=white
<pre>fitcurve(V,n,[e.g. dotted]</pre>	,m (def	ault 0))
	gen	Draw a spline through V[m],V[n]: Works only with dpic (and $n - m > 2$ ): V[m]:position; V[n]:position
for_(start, end, increment, 'acti	ons')	·
	gen	integer for loop with index variable m4x
fuse( <i>linespec</i> , type, wid, ht)	$\operatorname{cct}$	tuse symbol, type= $A B C D S HB HC$ or $dA=D$
g	gen	green color value
gap(linespec, fill, A)	$\operatorname{cct}$	gap with (filled) dots, A=chopped arrow between dots
gen_init	gen	initialize environment for general diagrams (customizable)
glabel_	$\operatorname{cct}$	internal general labeller
gpar_(element, element, separat.	ion) cct	two same-direction elements in parallel
<pre>gpolyline_(fraction, location,</pre>	) gen	internal to gshade
grid_(x,y)	$\log$	absolute grid location
ground(at location, T, N F S	L P E, cct	<pre>U D L R degrees) ground, without stem for nonblank 2nd arg; N=normal, F=frame, S=signal, L=low-noise, P=protective, E=European; up, down, left, right, or angle from horizontal (default -90)</pre>
gyrator(box specs, space ratio, p	oin lgth,[	N][V])
	$\operatorname{cct}$	Gyrator two-port wrapper for nport, N omits pin dots; V gives a vertical orientation.
gshade(gray value, A, B,, Z, A	A,B)	(Nets lest tree comments). Checks a schemen with several
	gen	(Note last two arguments). Shade a polygon with named vertices, attempting to avoid sharp corners
hoprad_	$\operatorname{cct}$	hop radius in crossover macro
ht_	gen	height relative to current direction
ifdpic( <i>if true</i> , <i>if false</i> )	gen	test if dpic has been specified as pic processor
ifgpic(if true, if false)	gen	test if gpic has been specified as pic processor
<pre>ifinstr(string,string,if true,if</pre>	false) gen	test if the second argument is a substring of the first
<pre>ifmfpic(if true.if false)</pre>	gen	test if mfpic has been specified as pic post-processor
ifmpost(if true.if false)	gen	test if MetaPost has been specified as pic post-processor
ifpgf(if true, if false)	gen	test if Tikz PGF has been specified as pic post-processor
ifpostscript(if true, if false)	gen	test if Postscript (dpic -r) has been specified as pic output format
ifpstricks(if true, if false)	gen	test if PSTricks has been specified as post-processor

<pre>ifroff(if true, if false)</pre>	$\operatorname{gen}$	test if ${\bf troff}$ or ${\bf groff}$ has been specified as post-processor
<pre>ifxfig(if true, if false)</pre>	gen	test if Fig 3.2 (dpic $-x$ ) has been specified as pic output format
<pre>igbt(linespec,L R,[L][[d]D])</pre>	$\operatorname{cct}$	left or right IGBT, L=alternate gate type, D=parallel diode, dD=dotted connections
in	$\operatorname{gen}$	absolute inches
<pre>inductor(linespec,W L,n,M)</pre>	$\operatorname{cct}$	inductor, arg2: narrow (default), W=wide, L=looped; arg3: <i>n</i> arcs (default 4); arg4: M=magnetic core
<pre>inner_prod(linear obj, linear ob</pre>	j)	
	gen	inner product of (x,y) dimensions of two linear objects
integrator(linespec, size)	cct	integrating amplifier
intersect_(line1.start, line1.e	gen gen	e2.start, line2.end) intersection of two lines
j_fet(linespec,L R,P,E)	$\operatorname{cct}$	left or right, N or P JFET, without or with envelope
larrow(label,-> <-,dist)	$\operatorname{cct}$	arrow $dist$ to left of last-drawn 2-terminal element
<pre>lbox(wid, ht, type)</pre>	gen	box oriented in current direction, type= e.g. dotted
left_	gen	left with respect to current direction
length3D(x,y,z)	3D	Euclidean length of triple x,y,z
lg_bartxt	$\log$	draws an overline over logic-pin text (except for xfig)
lg_pin(location, logical name, p	in label, log	$\label{eq:linear} \begin{array}{l} \texttt{n e s w[N L M][E], pinno, optlen)} \\ \text{comprehensive logic pin; $n e s w=$direction, $N=$negated, $L=$active low out, $M=$active low in, $E=$edge trigger} \end{array}$
lg_pintxt	$\log$	reduced-size text for logic pins
lg_plen	$\log$	logic pin length in in L_units
<pre>lin_leng(line-reference)</pre>	gen	calculate the length of a line
linethick_(number)	gen	set line thickness in points
ljust_	$\operatorname{gen}$	ljust with respect to current direction
llabel(label,label,label)	$\operatorname{cct}$	triple label on left side of the element
loc_(x, y)	$\operatorname{gen}$	location adjusted for current direction
log10E_	gen	constant $\log_{10}(e)$
log_init	$\log$	initialize environment for logic diagrams (customizable)
loge	$\operatorname{gen}$	logarithm, base $e$
lp_xy	$\log$	coordinates used by lg_pin
<pre>lpop(xcoord, ycoord, radius,</pre>	fill, zer gen	o ht) for lollipop graphs: filled circle with stem to (xcoord,zeroht)
<pre>lswitch( linespec, L R )</pre>	$\operatorname{cct}$	knife switch
lt_	gen	left with respect to current direction
manhattan	gen	sets direction cosines for left, right, up, down
<pre>memristor(linespec, wid, ht)</pre>	$\operatorname{cct}$	memristor element
microphone( U D L R degrees	, size)	
	$\operatorname{cct}$	microphone, $In1$ to $In3$ defined
mm	$\operatorname{gen}$	absolute millimetres

r = r + (l = r = r + l = r = r)	+	MOCEPT 1.4
mosiet(innespec,Lik,chars,E)		characters, envelope. arg 3 chars: [u] [d]B: center bulk connection pin; D: D pin and lead; E: dashed substrate; F: solid-line substrate; [u] [d]G: G pin to substrate at source; [u] [d]H: G pin to substrate at center; L: G pin to channel; Pz: parallel zener diode; Q: connect B pin to S pin; R: thick channel; [u] [d]S: S pin and lead u: arrow up; d: arrow down; [d]T: G pin to center of channel d: not circle; X: XMOSFET terminal; Z: simplified complementary MOS
m4xpand(arg)	$\operatorname{gen}$	Evaluate the argument as a macro
m4lstring(arg1,arg2)	gen	expand $arg1$ if it begins with sprintf or ", otherwise $arg2$
$m4\_arrow(linespec,ht,wid)$	$\operatorname{gen}$	arrow with adjustable head, filled when possible
m4xtract('string1',string2)	$\operatorname{gen}$	delete $string2$ from $string1$ , return 1 if present
n_	$\operatorname{gen}$	.n with respect to current direction
ne_	$\operatorname{gen}$	.ne with respect to current direction
neg_	$\operatorname{gen}$	unary negation
norator(linespec, width, ht)	$\operatorname{cct}$	norator two-terminal element
<pre>nport(box spec; other command)</pre>	ds, nw,ni cct	n,ne,ns,space ratio,pin lgth,style, other commands) nport macro (default 2-port)
<pre>nterm(box spec; other command)</pre>	ds, nw,ni cct	n,ne,ns,pin lgth,style, other commands) n-terminal box macro (default three pins)
<pre>nullator(linespec, width, ht)</pre>	$\operatorname{cct}$	nullator two-terminal element
nw_	gen	.nw with respect to current direction
<pre>opamp(linespec,label,label,size</pre>	, [P] [R] cct	<pre>, other commands) operational amplifier with -, + or other internal labels, specified size. P adds power connections, R swaps In1, In2 labels; the first and last arguments allow added customizations</pre>
open_arrow(linespec,ht,wid)	$\operatorname{gen}$	arrow with adjustable open head
par_(element, element, separation	on)	
	$\operatorname{cct}$	two same-direction, same-length elements in parallel
pc	gen	absolute points
pi_	gen	$\pi$
<pre>pmod(integer, integer)</pre>	gen	+ve $mod(M, N)$ e.g., $pmod(-3, 5) = 2$
<pre>point_(angle)</pre>	$\operatorname{gen}$	(radians) set direction cosines
<pre>polar_(x,y)</pre>	$\operatorname{gen}$	rectangular-to polar conversion
<pre>potentiometer(linespec, cycles</pre>	, fraction cct	nal pos, length,) resistor with taps T1, T2, with specified fractional positions and lengths (possibly neg)
print3D(x,y,z)	3D	write out triple for debugging
prod_(a,b)	$\operatorname{gen}$	binary multiplication
<pre>project(x,(y,(z)</pre>	3D	3D to 2D projection onto the plane perpendicular to the view vector with angles defined by setview(azim, elev)
<pre>psset_(PSTricks settings)</pre>	$\operatorname{gen}$	set PSTricks parameters
pt_	$\operatorname{gen}$	$T_{\!E\!}X$ point-size factor, in scaled inches, $(\texttt{*scale/72.27})$
r_	gen	red color value

rarrow(label,-> <-,dist)	$\operatorname{cct}$	arrow dist to right of last-drawn 2-terminal element
rect_(radius, angle)	gen	(radians) polar-rectangular conversion
relay(n,O C,R)	$\operatorname{cct}$	relay: n poles (default 1), default double throw or normally open or closed, $R$ =oriented to right (default left) of current direction
resetrgb	gen	cancel r_, g_, b_ color definitions
<pre>resistor(linespec,n E,chars)</pre>	$\operatorname{cct}$	resistor, n cycles (default 3), chars: $E=ebox$ , $Q=offset$ , $H=squared$ , $R=right$ -oriented
<pre>reversed('macro name',args)</pre>	) cct	reverse polarity of 2-terminal element
rgbdraw(color triple, drawing	comman	ds)
	gen	color drawing for PSTricks, pgf, MetaPost postprocessors
rgbfill(color triple, closed pa	th)	fill with arbitrary color
right	gen	sot current direction right
rivet	gen	right justify with respect to current direction
rjust_	gen	triple lebel on right side of the element
rate(radiang v v z)	2D	relates y y g about y avia
rot 2Dw (radians, x, y, z)	3D 2D	rotates x,y,2 about x axis
rot 2Dp (radians, x, y, z)	3D 2D	rotates x,y,z about y axis
rotsbz (radians, x, y, z)	3D	rotates x,y,z about z axis
rotbox(wid,ht,type)	gen	box oriented in current direction in [ ] block; type= e.g. dotted shaded "green". Defined internal locations: N, NE, E, SE, S, SW, W, NW.
<pre>rotellipse(wid,ht,type)</pre>	gen	ellipse oriented in current direction in [] block; e.g. Point_(45); rotellipse(,,dotted fill_(0.9)). Defined internal locations: N, S, E, W.
<pre>rpoint_(linespec)</pre>	gen	set direction cosines
rpos_(position)	gen	Here $+$ position
<pre>rrot_(x, y, angle)</pre>	gen	Here + vrot_(x, y, angle)
rs_box( $text$ , $expr1$ ,)	gen	like s_box but the text is rotated by text_ang (default 90) degrees
rsvec_(position)	gen	Here $+$ position
rt_	gen	right with respect to current direction
rtod_	gen	constant, degrees/radian
rtod	$\operatorname{gen}$	constant, degrees/radian
<pre>rvec_(x,y)</pre>	$\operatorname{gen}$	location relative to current direction
S_	$\operatorname{gen}$	.s with respect to current direction
$s\_box(text,expr1,\cdots)$	gen	generate dimensioned text string using <b>\boxdims</b> from <b>boxdims.sty</b> . Two or more args are passed to <b>sprintf()</b>
<pre>s_dp(name,default)</pre>	gen	depth of the most recent (or named) $\verb+s_box+$
s_ht(name,default)	gen	height of the most recent (or named) <b>s_box</b>
<pre>s_init(name)</pre>	gen	initialize <b>s_box</b> string label to <i>name</i> which should be unique
s_name	$\operatorname{gen}$	the value of the last s_init argument
s_wd(name,default)	$\operatorname{gen}$	width of the most recent (or named) $\verb+s_box+$

sc\_draw(dna string, chars, iftrue, iffalse)

	$\operatorname{cct}$	test if chars are in string, deleting chars from string		
se_	gen	.se with respect to current direction		
<pre>setrgb(red value, green value, b</pre>	olue valu gen	e, [name]) define colour for lines and text, optionally named (default lcspec)		
<pre>setview(azimuth degrees, elevat</pre>	ion degr 3D	ees) set projection viewpoint		
<pre>sfg_init(default line len, node</pre>	rad, arro cct	whd len, arrowhd wid) initialization of signal flow graph macros		
sfgabove	$\operatorname{cct}$	like above but with extra space		
<pre>sfgarc(linespec,text,text justif</pre>	ication, cct	cw ccw, height scale factor) directed arc drawn between nodes, with text label and a height-adjustment parameter		
sfgbelow	$\operatorname{cct}$	like below but with extra space		
<pre>sfgline(linespec,text,text justification)</pre>				
	$\operatorname{cct}$	directed straight line chopped by node radius, with text label		
<pre>sfgnode(at location,text,abov</pre>	e below cct	small circle options) small circle default white interior, with text label. The default label position is inside if the diameter is bigger than textht and textwid; otherwise it is sfgabove. Options such as fill or line thickness can be given.		
<pre>sfgself(at location, U D L R</pre>	degrees	, text, text justification, cw ccw, scale factor) self-loop drawn at angle angle from a node, with text label and a size-adjustment parameter		
shade(gray value, closed line spe	ecs)	fill arbitrary aloged gume		
abadabar (box aposition)	gen	har with adva shading		
sign (number)	gen	sign function		
sinc(number)	gon	the sine $(x)$ function		
sind(arg)	gen	sing of an expression in degrees		
cinucal (amplitude frequency	phase t	train track)		
sinusoia (ampitude, nequency,	gen	draws a sinusoid over the interval $(t_{\min, \max})$		
<pre>source(linespec,V v I i AC F </pre>	G Q L I cct	P S T X U string, diameter, R) source, blank or voltage (2 types), current (2 types), AC, or type F, G, Q, L, X or labelled, P = pulse, U = square, R = ramp, S = sinusoid, T = triangle; R = reversed polarity		
sourcerad_	$\operatorname{cct}$	default source radius		
sp_	gen	evaluates to medium space for gpic strings		
<pre>speaker( U D L R degrees,size</pre>	,H) cct	speaker, $In1$ to $In7$ defined; $H=horn$		
<pre>sprod3D(a,x,y,z)</pre>	3D	scalar product of triple x,y,z by a		
sum3D(x1,y1,z1,x2,y2,z2)	3D	sum of two triples		
$sum_(a,b)$	gen	binary sum		
<pre>svec_(x,y)</pre>	$\log$	scaled and rotated grid coordinate vector		
SW_	gen	sw with respect to current direction		
	8011	.5w with respect to current direction		

	$\operatorname{cct}$	SPST switch left or right, blank or closing or opening arrow, or button, D=dots
$ta_xy(x, y)$	$\operatorname{cct}$	macro-internal coordinates adjusted for ${\tt L} \mid {\tt R}$
thicklines_(number)	gen	set line thickness in points
thinlines_(number)	gen	set line thickness in points
thyristor(linespec,chars)	$\operatorname{cct}$	thyristor, chars: D=Diode, A=Open diode, UA=open diode with centre line, B=Bidirectional diode, C=Type IEC, G=Full-size gate terminal, R=Right orientation, E=envelope
<pre>tline(linespec, wid, ht)</pre>	$\operatorname{cct}$	transmission line, manhattan direction
tr_xy( <i>x</i> , <i>y</i> )	$\operatorname{cct}$	relative macro internal coordinates adjusted for $\tt L R$
tr_xy_init(origin, unit size, si	gn)	
	$\operatorname{cct}$	initialize tr_xy
transformer(linespec,L R,np	,[A][W I cct	<pre>_],ns) 2-winding transformer: left or right, np primary arcs, air core or wide or looped windings, ns secondary arcs</pre>
ttmotor(linespec, string, diam	eter, bru cct	motor with label
twopi_	$\operatorname{gen}$	$2\pi$
ujt( <i>linespec</i> ,R,P,E)	$\operatorname{cct}$	unijunction transistor, right, P-channel, envelope
unit3D(x,y,z)	3D	unit triple in the direction of triple x,y,z
up_	$\operatorname{gen}$	set current direction up
up	$\operatorname{gen}$	up with respect to current direction
<pre>variable('element', [A P L</pre>	[u]N] [( cct	<pre>C S], angle, length) overlaid arrow or line to indicate variable 2-terminal element: A=arrow, P=preset, L=linear, N=nonlinear, C=continuous, S=setpwise</pre>
vec_(x,y)	$\operatorname{gen}$	position rotated with respect to current direction
vlength(x,y)	$\operatorname{gen}$	vector length $\sqrt{x^2 + y^2}$
vperp(linear object)	$\operatorname{gen}$	unit-vector pair CCW-perpendicular to linear object
<pre>vrot_(x,y,xcosine,ycosine)</pre>	$\operatorname{gen}$	rotation operator
vscal_(number,x,y)	$\operatorname{gen}$	vector scale operator
W_	$\operatorname{gen}$	.w with respect to current direction
wid_	$\operatorname{gen}$	width with respect to current direction
winding(L R, diam, pitch, tu	rns, core cct	wid, core color) core winding drawn in the current direction; R=right-handed
xtal(linespec)	$\operatorname{cct}$	quartz crystal
<pre>xtract(string, substring)</pre>	gen	returns substring if present

## References

- [1] J. Bentley. More Programming Pearls. Addison-Wesley, Reading, Massachusetts, 1988.
- [2] A. R. Clark. Using circuit macros, 1999. Courtesy of Alan Robert Clark at http://ytdp.ee. wits.ac.za/cct.html.

- [3] The Free Software Foundation. Gpic man page, 1992.
- [4] D. Girou. Présentation de PSTricks. Cahiers GUTenberg, 16, 1994. http://www.gutenberg. eu.org/pub/GUTenberg/publicationsPDF/16-girou.pdf.
- [5] M. Goossens, S. Rahtz, and F. Mittelbach. The LATEXGraphics Companion. Addison-Wesley, Reading, Massachusetts, 1997.
- [6] J. D. Hobby. A user's manual for MetaPost, 1990.
- [7] B. W. Kernighan and D. M. Richie. The M4 macro processor. Technical report, Bell Laboratories, 1977.
- [8] B. W. Kernighan and D. M. Richie. PIC—A graphics language for typesetting, user manual. Technical Report 116, AT&T Bell Laboratories, 1991.
- [9] Thomas K. Landauer. The Trouble with Computers. MIT Press, Cambridge, 1995.
- [10] E. S. Raymond. Making pictures with GNU PIC, 1995. In GNU groff source distribution.
- [11] T. Rokicki. DVIPS: A T<sub>F</sub>X driver. Technical report, Stanford, 1994.
- [12] R. Seindal et al. GNU m4, 1994. http://www.gnu.org/software/m4/manual/m4.html.
- [13] T. Van Zandt. PSTricks user's guide, 1993.